

CATS User Manual





Contents

Glossary	4
1 Disclaimer	6
2 Important Regulatory Information	7
2.1 FCC Part 15 Compliance	7
2.2 Intended Use and Operational Constraints	7
2.3 Hardware Certification and Radio Frequency (RF) Operations	7
2.4 European Union (EU) and CE Compliance Notice	7
2.5 Environmental and Safety Declarations	7
3 Introduction	8
3.1 Coverage of This Manual	8
3.2 Module Overview	8
3.3 Basic Functionality	8
4 CATS Vega	9
4.1 Hardware	9
4.1.1 Specifications	9
4.1.2 Hardware Overview	10
4.2 Working Principle	10
4.2.1 Configurable Actions & Finite State Machine	11
4.2.2 Actions	12
4.3 How to Use	13
4.3.1 Connection to Your Computer	13
4.3.2 Description of the Configurator	13
4.3.3 Mounting	18
4.3.4 Battery, Switch and Actuators	18
4.3.5 Setting up the Minimal Flight Configuration	21
4.3.6 How to Get the Data on Your Computer	22
4.3.7 Visualizing the Flight Data	22
4.3.8 Software Updates	22
4.4 Beeping Patterns	23
5 Ground Station	24
5.1 Hardware	24
5.1.1 Overview	24
5.1.2 Specifications	25
5.2 How to Use	25
5.2.1 Explanation of All Menus	25
5.2.2 Telemetry Modes	28
5.2.3 Data Streaming via USB	29
5.2.4 Charging	30
5.2.5 How to Get the Data on Your Computer	30
5.2.6 Software Updates	30
6 Firmware Updates	31
6.1 Before Updating	31
6.2 Updating the Configurator	31
6.3 Updating the CATS Vega	32
6.4 Updating the Ground Station	32
6.5 Updating the Ground Station Radio Receivers	33



6.6 Recovering an Interrupted Update	34
7 Example Configurations	35
7.1 Simple Dual-Deployment Example	35
7.2 Advanced Recovery Example	35
8 Testing	37
8.1 What Testing Mode Does	37
8.2 Before You Start	37
8.3 Enabling and Using Testing Mode	37
8.4 Returning to Flight Configuration	38
9 Advanced Information	39
9.1 Software Overview	39
9.2 Telemetry	40
9.3 Estimation Algorithms	41
9.4 Using the Python Plotting Tool	43
9.5 Common CLI Commands	44
10 FAQ and Troubleshooting	47



Glossary

Apogee	The highest point of the rocket during a parabolic flight. 8, 11, 21
Barometer	A sensor that measures ambient barometric pressure. 9, 39
Calibrating	A flight state in which the flight computer is in safe mode and performs no actions. 11, 23, 41
CLI	Command Line Interface, used to read and change flight-computer values without the Configurator. 13, 45
CRC	Cyclic Redundancy Check, used to verify that received data is not corrupted. 40
Drogue Chute	A relatively small parachute deployed at apogee to stabilize and slow the rocket during descent. 21
FHSS	Frequency Hopping Spread Spectrum, a protocol that transmits telemetry data across multiple carrier frequencies. 40
FreeRTOS	An operating system for embedded CPUs and the backbone of the CATS software. 39
FSM	Finite State Machine, a model that describes the flight phases, how transitions between them occur, and which transitions are permitted. 11
GNSS	Global Navigation Satellite System, such as GPS or Galileo. 10, 18
I/O	Input/Output, a collective term for the system's inputs and outputs. 8, 10, 18, 19, 20
IMU	Inertial Measurement Unit, a sensor that measures linear acceleration and angular velocity. 9, 11, 39
Kalman Filter	A filtering technique used to estimate states according to physical laws and measurements. 41
Liftoff	The event that marks the start of powered ascent. 11, 12, 18, 21, 41, 42
Main Chute	The larger parachute deployed at a specified height above ground level to slow the rocket before landing. 21
Patch Antenna	A flat, highly directional antenna used by the CATS Vega to receive GNSS signals. 18
Power Supply	A source of electrical power, typically a battery in a rocket. 8, 19
PWM	Pulse Width Modulation, a method used to control most modern servos. 19
Pyro	A pyrotechnic charge initiated by applying current through two electrical leads. 9, 10, 11, 12, 18, 19, 20
Ready	A flight state; when in this state, liftoff can be detected. 11, 18, 22, 23, 41
RF	Radio Frequency. 18



Servo	A small electric actuator whose position is controlled by a PWM signal. 9, 11, 12, 18, 19, 20, 21
Touchdown	The final flight phase, entered when the rocket lands. 11
UART	A serial communication interface used to exchange data between devices. 9, 10



1 Disclaimer

The use of the CATS System is at your own risk. The CATS System must always be used in conjunction with a second safety system that operates in a different manner, such as motor ejection or another electronic system, to ensure maximum safety.

The manufacturer is not liable for any damages that may occur as a result of using the CATS System, and will not be held responsible for any damages inflicted on third parties.

Do not touch the CATS Vega while it is powered through the battery port because high currents flow through the board.

The manufacturer cannot be held liable for any program errors or malfunctions in the software.

The hardware warranty covers manufacturing errors and defects in workmanship and materials for a period of two years from the date of purchase. This warranty does not cover damage caused by improper handling, accidents, or other external factors. In the event of a covered manufacturing error or defect, the manufacturer will repair or replace the hardware at no cost to the user. To make a claim under this warranty, the user must provide proof of purchase and report the issue to the manufacturer within the warranty period. The manufacturer reserves the right to inspect the hardware and determine the cause of any reported issue before providing a repair or replacement. This warranty is non-transferable and only applies to the original purchaser of the hardware.



2 Important Regulatory Information

2.1 FCC Part 15 Compliance

This equipment has been designed to operate in accordance with Part 15 of the FCC Rules for unlicensed radio frequency devices. To maintain cooperative use of the shared spectrum, operation should be subject to two general conditions: (1) the device should not cause harmful interference, and (2) it must accept any interference received, including interference that may cause undesired operation.

2.2 Intended Use and Operational Constraints

The CATS Vega and Ground Station are developed primarily for educational, professional, and experimental use within amateur High Power Rocketry. In the United States, rockets of this class are considered aircraft by the Federal Aviation Administration (CFR 14 §101.25). Operators should adhere to FAA and National Fire Protection Association (NFPA) safety codes, which typically require maintaining a safe distance of at least 1,500 feet from populated buildings or uninvolved persons. Due to the high-power radio frequency emissions in the 2.4 GHz band, users are strongly advised against operating this telemetry system in residential areas to prevent potential disruptions to local consumer networks.

2.3 Hardware Certification and Radio Frequency (RF) Operations

The system utilizes Semtech SX1280 RF modules operating in the 2.4 GHz Industrial, Scientific, and Medical (ISM) band. As this operates on a shared, unlicensed band, users are not protected against interference from other ambient RF sources. We have made good faith efforts to ensure the hardware design follows standard EMC practices; however, should your system cause interference with licensed radio systems or residential Wi-Fi networks, you are expected to power down the device until the interference issue is resolved.

2.4 European Union (EU) and CE Compliance Notice

For operation within the European Union (EU) and the European Economic Area (EEA), this equipment is subject to the Radio Equipment Directive (RED) 2014/53/EU. Users operating within the EU must configure the telemetry output via the CATS Configurator to comply with the ETSI EN 300 328 harmonized standard, which strictly limits 2.4 GHz wideband transmissions to a maximum of 100 mW (20 dBm) Equivalent Isotropic Radiated Power (EIRP).

Exception for Licensed Amateur Radio Operators: Users holding a valid amateur radio license are authorized to operate at higher power levels within the 2.4 GHz amateur allocation. Such operation must strictly adhere to national amateur radio regulations, including station identification rules and prohibitions on encrypted commercial data.

2.5 Environmental and Safety Declarations

This product is factory-assembled utilizing lead-free manufacturing processes with the intent of aligning with global Restriction on Hazardous Substances (RoHS) principles. Please practice responsible disposal at the end of the product's life cycle by recycling it as electronic waste rather than disposing of it in standard household trash.



3 Introduction

Welcome to the CATS User Manual. The following pages explain the CATS System so that you can install, configure, test, fly, and recover a rocket using the CATS Vega flight computer and CATS Ground Station. Each component has a practical operating section, while later chapters provide additional technical detail.

If you have feedback, suggestions, or need further help, contact us on our Discord server. The CATS ecosystem is open source; source code and hardware designs are available on our GitHub page.

3.1 Coverage of This Manual

This manual covers the use of the CATS Vega flight computer and its Ground Station. It explains how the flight computer works, how to connect it to a Power Supply and deployment actuators, and how to configure it for your flight trajectory.

This manual does not cover everything that can be done with the CATS System. In particular, it does not explain how to modify the software or hardware, or how the software works in detail. For further information about those topics, contact us on our Discord server.

3.2 Module Overview

The CATS System has three main components.

CATS Vega: The flight computer installed inside your rocket.

Ground Station: The receiver that displays and records telemetry, supports recovery, and controls bench testing.

Configurator: The desktop application used to configure and update the CATS Vega, review a configuration before flight, manage profiles, and analyze completed flights.

3.3 Basic Functionality

This section provides a broad overview of the CATS System for users who are new to rocketry. The following sections explain each topic in greater detail.

The CATS Vega is the core of the system. Its main purpose is to deploy the drogue chute at Apogee and the main chute at a user-configurable height above ground level. To do this, it combines barometric and accelerometer data to estimate height above ground level and velocity.

The CATS System defines five **events**: *Liftoff*, *Burnout*, *Apogee*, *Main Deployment*, and *Touchdown*. The onboard control system triggers these events automatically, while the user defines the actions performed when each event occurs.

Up to eight **actions** can be assigned to each event. Actions include delays, pyro-channel and servo-channel triggers, and low-level I/O signals. This allows the user to define how the deployment mechanism is actuated. Most commercial recovery mechanisms use pyro or servo channels, and the CATS Vega provides two of each.

At the same time, the system transmits important data to the Ground Station, including GNSS data, current height, velocity, and flight state. The data is also recorded in onboard flash memory.

The Ground Station is also used for testing mode, in which the user can trigger configured events to test separation mechanisms.



4 CATS Vega

This section describes how the flight computer works and how to configure it for a flight. The How to Use section explains its basic features. For more detailed information, refer to Section 9 .




Figure 1: CATS Vega

4.1 Hardware

4.1.1 Specifications

Size	100×33×15mm (without the antenna)
Weight	33g
Input Voltage	7-24V
Power Consumption	100mA
Number of Pyro channels	2
Number of Servo channels	2
Number of IOs	1
Additional IO	UART
Servo Power	5V / 3A max.
Microcontroller	STM32F4
Flash Memory	16MB
IMU	LSM6DSO32
Barometer	MS5607
Radio Frequency	ISM 2.4GHz
Radio Power	Up to 1W
Radio Range	Tested to 10km @100mW

Table 1: Vega Specifications



4.1.2 Hardware Overview

This section provides a quick hardware overview and shows the location of each port. The numbered markers in Figure 2 correspond to the following list.

1. **Switch Port;** Connect a manual switch between the two terminals.
2. **Battery Port;** Connect a battery to these terminals and observe the correct polarity.
3. **Buzzer;** Indicates flight-computer readiness and status through beeping patterns, as explained in Section 4.4 .
4. **Status LEDs;** The POWER LED is illuminated when power is present. The STATUS LED blinks when the system is operating normally.
5. **USB Connector;** The connector is on the other side of the board.
6. **Test Button;** If this button is held during startup, the board enters testing mode if a testing phrase has been configured.
7. **Servo Connector;** This connector fits the standard servo connectors. Two servos can be connected to this connector.
8. **Telemetry LEDs;** The GNSS LED blinks whenever GNSS coordinates are received. The LINK LED blinks after a connection to the Ground Station has been established.
9. **Low-Level I/O and UART Connector;** Connect external hardware to this port to exchange data with the CATS board.
10. **Pyro LEDs;** These red LEDs are turned on when continuity of the Pyro channel is detected.
11. **Pyro Channel 1;** Connect a pyrotechnic charge or another supported device to this connector.
12. **Pyro Channel 2;** Connect a pyrotechnic charge or another supported device to this connector.
13. **Antenna Connector;** Connect an antenna here so that the CATS Vega can transmit data to the Ground Station.




Figure 2: CATS Vega board hardware specifications

4.2 Working Principle

This section briefly introduces the operating principles needed to understand the Vega flight computer's configuration options.



4.2.1 Configurable Actions & Finite State Machine

The finite state machine (FSM), shown in Figure 3, controls the outputs of the Vega flight computer. When the flight computer is turned on, it starts in the Calibrating state. Every flight follows the sequence of states shown in Figure 3. Whenever a state transition occurs, the associated event is triggered.




Figure 3: Finite State Machine controlling the CATS software.

Each event can trigger one or more actions, such as a Pyro channel, Servo channel, or timer. Use the Configurator to assign actions to events, as described in Section 4.3.2.

Calibrating → Testing	A telemetry command starts testing mode. This transition is available only if testing mode was enabled through the Configurator.
Calibrating → Ready	IMU (gyroscope and linear acceleration) readings are constant for 10 seconds.
Ready → Thrusting	The measured acceleration in any direction exceeds the user-defined acceleration threshold for 0.1 seconds.
Thrusting → Coasting	The measured acceleration in the “up” direction is smaller than $0 \frac{m}{s^2}$ for 0.1 seconds
Coasting → Drogue	The estimated velocity needs to be smaller than $0 \frac{m}{s}$ for 0.3 seconds
Drogue → Main	The estimated height is below the user-defined height for 0.3 seconds
Main → Touchdown	The estimated velocity is in the bound $[-3, 3] \frac{m}{s}$ for 1 second

Table 2: FSM Transition Specifications

With this setup for state changes, the flight has a strictly controlled order. The Main event can only be thrown after the Apogee event. Events are also **unique**; during a flight only one event can be thrown.

Note: A software safeguard checks the time between Liftoff and Apogee. If that time is smaller than 1.5 seconds, the flight computer assumes a faulty Liftoff detection and no further events or actions are activated. The flight computer then jumps instantly to Touchdown without triggering anything.



4.2.2 Actions

When an event is triggered, the flight computer performs the actions assigned to it. Up to eight actions can be assigned to each event, supporting a wide range of applications. Examples include:

- Enabling a camera at Liftoff using a Pyro channel,
- Actuating a solenoid valve for two seconds using a Pyro channel,
- Enabling some mechanism at engine burnout,
- Disabling the camera at touchdown using the Pyro channel,
- ...

The full range of actions can be found below.

Action	Parameter
Pyro 1	ON/OFF
Pyro 2	ON/OFF
Servo 1	[0-1000]‰
Servo 2	[0-1000]‰
Low-Level I/O	ON/OFF
Delay	[0-15000] ms
Recorder	ON/OFF/PREFILLING

Table 3: Exhaustive List of all possible Actions

Note: The *PREFILLING* recorder option continuously accumulates log elements in a buffer. Once the recorder transitions into *ON* mode, the elements in the buffer are written to the flash chip. This information can be used to analyze the initial ignition sequence and thrust build-up.

How actions can be configured is shown in section 7 .



4.3 How to Use

Now that the hardware and software have been introduced, this section explains how to configure and mount the flight computer, update its software, and generate plots from flight data.

4.3.1 Connection to Your Computer

Before connecting your CATS Vega to your computer, download the Configurator from our releases page. Drivers are usually not required. If your computer does not recognize the device, refer to the troubleshooting steps in our wiki¹.

4.3.2 Description of the Configurator

The Configurator is the desktop application used to configure the CATS Vega, inspect its status, manage configuration profiles, run a preflight review, update firmware, and analyze flight logs. Download the latest release from the Configurator releases page².

When exactly one compatible Vega is connected, the Configurator selects it and connects automatically. If no automatic connection is made, use the device selector in the upper-right corner, choose the intended Vega, and select **Connect**. Use the refresh button if a newly connected device is not listed. When several Vegas are connected, always verify the selected device before changing or saving a configuration.

The left navigation provides the following work areas:

Configuration	Flight settings, telemetry, testing, recorder settings, live board status, and hardware information.
Events & Timers	Actions assigned to flight events and the four configurable timers.
Profiles	Export the connected board configuration, compare another profile, and apply compatible settings.
Preflight	A read-only review of the configuration, warnings, event sequence, timers, and outputs.
CLI	Direct access to advanced flight-computer commands.
Flight Logs	Open local or onboard <code>.cfl</code> logs, generate plots, export data, or open a log in CATS Flights.
Firmware Updates	Detect supported devices, retrieve official releases, and install or prepare firmware.
Flights	Open CATS Flights in the default browser.

Table 4: Configurator navigation

4.3.2.1 Configuration

The Configuration page groups flight settings into General, Telemetry, Testing, Recording, Info, and Hardware Info panels. The General panel contains the main-deployment altitude, liftoff threshold, and initial servo positions. For most flights, use a liftoff threshold of $40 \frac{m}{s^2}$ unless testing with the complete rocket shows that another value is required. The Telemetry and Testing panels contain the enable controls and phrases used by the Ground Station.

Changes shown in the Configurator are not persistent until **Save** is selected. Use **Refresh** to discard unsaved edits and reload the values stored on the Vega. **Reset Config** restores the default configuration after confirmation.

¹<https://github.com/catsystems/cats-embedded/wiki/Installation>

²<https://github.com/catsystems/cats-configurator/releases>



4.3.2.2 Events & Timers

The Events & Timers page shows all flight events and their assigned actions, followed by the four timers. Select **Add Action** to add an output, recorder command, or delay to an event. Existing actions can be edited or removed. Up to eight actions can be assigned to each event. Select **Save** after changing events or timers.

Each timer has a start event, a duration, and an event to trigger when the duration expires. A timer can provide a backup event or trigger Custom 1 or Custom 2 for a payload sequence. Triggering an event through a timer does not force the flight-state estimator into the corresponding state.


Note: Flight events are unique during normal operation. If both the estimator and a timer could trigger the same event, only the first occurrence is processed.

The screenshot shows the CATS Configurator web interface. The top navigation bar includes the CATS logo, the title 'CATS Configurator', and a 'Disconnect' button. The left sidebar lists various configuration categories: Configuration, Events & Timers, Profiles, Preflight, CLI, Flight Logs, Firmware Updates, and Flights. The main content area is divided into several sections:

- General:** Contains input fields for 'Main Altitude' (300 m), 'Liftoff Detection Acceleration' (45 m/s²), 'Initial Position Servo 1' (0 %), and 'Initial Position Servo 2' (0 %). A red 'Reset Config' button is located below these fields.
- Telemetry:** Contains a dropdown for 'Enable Telemetry' (set to ON), a text field for 'Link Phrase' (example-link), a dropdown for 'Telemetry Power Level' (16 dBm), and a dropdown for 'Adaptive Power Level' (OFF).
- Info:** Displays system information: 'System time: 1691628 ticks', 'State: READY', 'Voltage: 0.24V', and 'h: 0.13m, v: 0.15m/s, a: 0.01m/s²'.
- Testing:** Contains a dropdown for 'Enable Testing Mode' (set to OFF) and a text field for 'Testing Phrase' (example-test).

At the bottom of the interface, there is a status bar with the following information: 'Status: Connected', 'Board: CATS Vega', 'Code version: 3.0.2', 'Telemetry Code version: 1.2.3', and 'App version: 2.0.0'. A 'Refresh' button and a 'Save' button are also present in the bottom right corner.

(a) Review and edit the connected Vega configuration.



(b) Review event actions and timer configuration.

Figure 4: Configurator Configuration and Events & Timers pages

4.3.2.3 Profiles

The Profiles page can export the complete connected-board configuration as a JSON profile. Opening another profile shows a setting-by-setting comparison with the connected Vega, including differences in configuration, events, timers, and recorder settings. Review compatibility warnings before applying a profile. You can apply the full compatible profile or individual differing settings, then save the resulting configuration to the board.

4.3.2.4 Preflight

The Preflight page reads the saved board configuration and produces a report without changing it. Run Preflight after saving the final configuration. Review every error and warning, especially testing mode, telemetry and recording status, deployment actions, liftoff threshold, timer cycles, and event ordering. The event timeline summarizes which actions run at each flight event and which active timers may trigger additional events.

Preflight is an additional configuration review, not a substitute for continuity checks, deployment-system testing, range procedures, or a redundant recovery system.



CATS Configurator
CONTROL & TELEMETRY SYSTEMS

Configuration Profiles

Review the connected board profile at any time, export it as JSON, or open another profile for a setting-by-setting comparison.

Export Board Profile Open Profile Reset Config

Connected Board Profile Comparison Refresh Board

Board: CATS Vega Firmware: 3.0.2 Schema: 1 Captured: 9/14/2026, 1:45:26 PM

Showing 21 board settings read from the connected board.

Section	Setting	Current board value
Configuration	Main Altitude main_altitude	300 m
Configuration	Liftoff Detection Acceleration acc_threshold	45 m/s ²
Configuration	Initial Position Servo 1 servo1_init_pos	0
Configuration	Initial Position Servo 2 servo2_init_pos	0
Configuration	Enable Telemetry tele_enable	ON
Configuration	Link Phrase tele_link_phrase	example phrase
Configuration	Telemetry Power Level tele_power_level	16
Configuration	Adaptive Power Level tele_adaptive_power	OFF
Configuration	Enable Testing Mode test_mode	OFF
Configuration	Testing Phrase tele_test_phrase	example phrase

Status: Connected Board: CATS Vega Code version: 3.0.2 Telemetry Code version: 1.2.3 App version: 2.0.0

(a) Inspect the connected-board profile or compare another profile before applying it.

CATS Configurator
CONTROL & TELEMETRY SYSTEMS

Preflight Check

Run Preflight

This is a read-only check. It simulates the configured event and timer sequence without enabling test mode or activating any output. Findings are advisory warnings and do not disable Configurator operations.

READY
All required safety checks passed.
CATS Vega 3.0.2 · 9/14/2026, 1:46:33 PM

0 Warnings 6 Ready checks

Preflight Report

- Testing mode is off
Board mode - The board is using normal flight behavior. ready
- Liftoff threshold is within the usual range
Flight detection - Liftoff detection acceleration is 45 m/s². ready
- Flight recording starts and stops
Recording - Recording starts at Liftoff and stops at Touchdown. ready
- Apogee and main deployment outputs are configured
Deployment - Apogee and main deployment use configured outputs; main altitude is 300 m. ready
- Timer chains are valid
Timers - No timers are active. ready

Event & Timer Simulator
Flight events and independently triggered timer chains

Flight Event Sequence

- Liftoff** event
Flight event: LIFTOFF
Liftoff detection: 45 m/s²
Recorder: LOG
- Burnout / Max V** event
Flight event: MAX_V
No configured actions
- Apogee** event
Flight event: APOGEE
Pyro 1: ON Delay: 2000 ms Pyro 1: OFF
- Main Deployment** event
Flight event: MAIN_DEPLOYMENT
Deployment altitude: 300 m

Status: Connected Board: CATS Vega Code version: 3.0.2 Telemetry Code version: 1.2.3 App version: 2.0.0

(b) Run the read-only Preflight review after saving the final configuration.

Figure 5: Configurator Profiles and Preflight pages

4.3.2.5 CLI

The CLI page sends commands directly to the connected Vega. It is intended for advanced inspection and troubleshooting; normal configuration should be performed through the other pages. Common commands are listed in Section 9.5 .



4.3.2.6 Flight Logs

The Flight Logs page accepts one Vega `.cfl` file selected through the file picker or dropped anywhere in the Configurator window. When a Vega USB drive is mounted, the page also lists its onboard logs. An onboard log can be viewed locally, saved as a copy, deleted from the Vega, or opened in CATS Flights.

After opening a log, use **Export CSV** for tabular data or **Export HTML** for interactive plots. **Open in Flights** hands the selected log to CATS Flights through the local browser; the log remains on the computer unless it is explicitly saved or shared there.




Figure 6: Configurator Flight Logs page with a connected Vega



4.3.3 Mounting

The CATS Vega **does not** require a specific mounting orientation. The system automatically detects the gravity vector for internal state estimation, so you can mount the board in any orientation.

The board has a length of 100mm, a width of 33mm and a total height of 15mm. Three mounting holes are spaced 60mm by 27mm and are designed for M3 screws. Use spacers to prevent the electronics from touching the rocket. Download the system's 3D files from our GitHub repository³. For reliable radio reception during flight, pay close attention to the area surrounding each antenna. Install the CATS flight computer in a radio-transparent section of the rocket, such as fiberglass or cardboard. Do not install it in a carbon-fiber section, which blocks RF signals. Ensure that the onboard Patch Antenna has a clear view of the sky for optimal GNSS reception, and keep the telemetry antenna away from metal objects.

After power-up, the system detects the up direction once it is stable. A beeping pattern and the Ground Station indicate when the flight computer enters the Ready state. In this state, the flight computer is armed and waiting for Liftoff. Do not move the rocket, and follow all safety guidelines. At this stage, the flight computer can be disarmed only by switching it off. For more information about calibration, refer to Sections 9.3 and 4.2.1 .




Figure 7: CATS Vega board with the mounting hole and dimensions.

Warning: Power up the flight computer only after the rocket is upright on the launch pad. Calibration is performed once, as soon as no motion is detected after startup.

4.3.4 Battery, Switch and Actuators

The CATS Vega has one battery port, one switch port, two Pyro channels, two Servo channels, and one low-level I/O. The following sections briefly explain each port. Table 5 summarizes the most important parameters. For more information about the board hardware, refer to Section 4.1 and the labeled board diagram in Figure 2 .

Battery Port

The battery port supports 7 to 24 volts. Use a 2- to 5-cell LiPo or Li-ion battery and ensure that its actual voltage remains within this range. The battery port is protected against reverse polarity.

Switch Port

The switch port allows the user to add a mechanical switch to the system. If this switch is turned off, the system is fully disconnected from power.

³<https://github.com/catsystems/cats-hardware/tree/main/CATS-Vega/3D>



Note: The battery current is routed through the switch. Make sure that the wires and the switch are rated for the currents required.

Pyro Channels

The Pyro channels apply the battery voltage to the connected circuitry with a voltage drop of approximately 1 V. An electric match is normally connected to a channel to ignite a black-powder charge. The channels can also power other devices. For example, they can actuate solenoid valves (with an external flyback diode), power cameras, or power other electronic circuits. By default, the maximum continuous current is approximately 1 A. The channels are short-circuit protected by a resettable PTC fuse. This current is more than sufficient to ignite electric matches before the fuse reduces it. If the connected load requires more current, the fuse can be bypassed with a solder jumper on the back of the board. In this configuration, stay below 5 A continuous or 20 A burst. Exercise extreme caution: a short circuit on the channel can damage the board.

Warning: The pyro channels are short-circuit protected by a resettable PTC fuse. If the connected circuit requires more than 1 A, close the solder bridge on the back of the board.

Servo Channels

The Servo channels can actuate PWM Servos. An onboard voltage regulator reduces the battery voltage to 5 V to power the servos. The microcontroller's power rail is completely separate from the 5 V Power Supply therefore, a short circuit on the servo power rail does not affect the system. A maximum current of 3 A can be drawn. A PWM signal is always applied to each Servo channel, and the endpoints can be changed in the Configurator.

Low-Level I/O

The low-level I/O can send a signal to another system. The voltage level is 3.3 V, and the pin is connected directly to the microcontroller. Therefore, the I/O should be used **only** for signal transmission, not to actuate a recovery mechanism.



I/O Specification

I/O	Description	Limits
Battery Port	Connect battery	7-24V
Switch Port	Connect mechanical switch	n.a.
Pyro Channels	Connect up to two pyrotechnic charges or other devices	Battery voltage / 5A
Servo Channels	Used for Servo actuation, up to two Servos	5V / 3A
Low-Level I/O	Use only for signal transmission, not actuation	3.3V / 10mA

Table 5: Overview of the I/Os



4.3.5 Setting up the Minimal Flight Configuration

For nominal flight performance, several parameters must be configured before every flight. In particular, the user must know:

- Expected maximum acceleration
- Recovery mechanism for the Drogue Chute
- Recovery mechanism for the Main Chute
- Time until Apogee (optional)
- Desired deployment altitude of the Main Chute
- Time until Main Chute deployment (optional)

With this information, the user can configure the flight computer. Timers are optional and should be used only as a backup.

1. Connect the flight computer to your computer.
2. Open the Configurator and connect to the board as described in Section 4.3.2 .
3. On the **General** page, set the Liftoff threshold. We recommend using a Liftoff acceleration threshold of $40 \frac{m}{s^2}$, but make sure that it is around $20 \frac{m}{s^2}$ lower than your maximum expected acceleration.
4. On the **General** page, set the main altitude to your desired height. This is the height above ground level where the Main Chute will be deployed.
5. If you use a Servo channel in either of your recovery mechanisms, it is now also the time to set the initial Servo position.
6. On the Configurator's **General** page, set the link phrase for your CATS Vega.
7. Make sure that the Testing Mode is disabled.
8. Save the settings.
9. Open the **Events & Timers** page.
10. For the apogee event, set your deployment mechanism as described in 4.3.2 .
11. For the main deployment event, set your deployment mechanism as described in 4.3.2 .
12. Save the settings.
13. (Optional) On the same page, open the timers section.
14. (Optional) Set the Timer One start event to Liftoff and the Timer One end event to apogee. Set the time until apogee with 1-2 seconds margin.
15. (Optional) Set the Timer Two start event to Liftoff and the Timer Two end event to main deployment. Set the time until main deployment with 10-60 seconds margin, depending on the flight time.
16. Save the settings.
17. Set the same link phrase on your Ground Station. Navigate to Settings, select Link Phrase, and enter the same phrase.



The flight computer is now ready to be installed in the rocket. For this flight configuration, complete the following steps:

1. Mount the flight computer to your rocket.
2. Connect the switch to the switch port.
3. Connect the battery to the battery port.
4. Connect the recovery mechanism for the apogee event.
5. Connect the recovery mechanism for the main event.
6. Place the rocket on the launch pad.
7. Turn on the flight computer with the switch.
8. The Ground Station will begin receiving data.
9. Wait for the flight computer to finish calibrating and show READY on the Ground Station.
10. The flight computer is now armed. Every 6 seconds, the flight computer beeps twice to indicate that it is in the Ready state.
11. Launch your rocket!

4.3.6 How to Get the Data on Your Computer

After the flight, connect the board to a computer with a USB-C cable. The flight computer appears as a USB drive containing `.cfl` flight logs and their associated files. Copy the required files before disconnecting the board, or use the Configurator's Flight Logs page to browse, view, save, or delete onboard logs.




Figure 8: USB drive when the CATS Vega is plugged into the user computer.

4.3.7 Visualizing the Flight Data

Open the Configurator's Flight Logs page and choose or drop a `.cfl` flight log. The Configurator plots altitude, velocity, acceleration, angular velocity, linear acceleration, pressure, state changes, and actions. Export the data as `.csv` files for further processing or as an `.html` file with interactive plots. You can also open the log in CATS Flights. A legacy Python plotting tool is described in Section 9.4 for users who need a customizable local workflow.

4.3.8 Software Updates

Use the Configurator's Firmware Updates page for normal Vega updates. The complete procedure, including Ground Station and radio-receiver updates, is described in Section 6.



4.4 Beeping Patterns

The CATS Vega flight computer uses beeping patterns to indicate its current state or a potential error. The tables below list the available patterns.






State	Description	Pattern
Bootup	The flight computer has booted up.	
Calibrating → Ready	The flight computer has switched from the Calibrating state to the Ready state.	
Ready	Calibration was successful, and the flight computer is in the Ready state.	
Testing	The flight computer is in testing mode. This pattern sounds only after the computer is rebooted.	
Testing Armed	The flight computer is in the armed testing state.	

Table 6: Overview of state beeping patterns.

Note: The pitch axis shows only relative, unitless changes.

Note: Bad calibrations usually happen when the flight computer is turned on and then rotated. Only turn the flight computer on once the rocket is in launch configuration and upright on the launch pad.

Note: Audible error codes are not currently implemented. Errors are shown only through telemetry on the Ground Station. Audible error codes will be added in a future update.



5 Ground Station

The Ground Station is the counterpart to the CATS Vega. It receives data from the flight computer and sends commands to it. It displays the rocket's position, velocity, system health, and other important information in real time. This chapter explains how to use the Ground Station and describes its operating principle.



Figure 9: Ground Station

5.1 Hardware

5.1.1 Overview

The Ground Station is built around an ESP32-S2 microcontroller and features a transfective display that remains readable in bright sunlight. It has 4 MB of internal flash, including a 1 MB FAT data partition for logs and firmware-transfer files.



5.1.2 Specifications

Microcontroller	ESP32-S2
Flash Memory	4 MB internal; 1 MB data partition
Battery	Li-Ion 18650
Power Consumption	60mA
Charging Current	500mA
Screen	LS027B7DH01
Radio	2x SX1280
Radio Range	Tested to 10km @100mW
GNSS	ATGM336H-5N

Table 7: Ground Station Specifications

5.2 How to Use

This section covers the basic use of the Ground Station. For more advanced information, refer to the later sections.

5.2.1 Explanation of All Menus

Use the joystick to move left, right, up, and down. Press A to open a menu, select an item, or confirm an action. Press B to go back. Arrows and hints at the edges of the display indicate when another page or action is available.




Figure 10: Ground Station main menu

5.2.1.1 Live

The Live screen shows telemetry from the connected Vega or Vegas. It displays flight state, altitude, vertical velocity, battery voltage, pyro continuity, errors, and radio-link information. Press Left for the GNSS view and Right for the downrange view. The downrange view uses the Ground Station's own GNSS position to show the rocket's relative direction and distance.

The link indicators include:



- **AGE** - Time since the last received packet. A link is treated as disconnected after five seconds without a packet.
- **SNR** - Signal-to-noise ratio in dB. Lower values indicate a noisier radio environment.
- **LQ** - Percentage of expected packets received during the recent measurement window.
- **RSSI** - Received signal strength in dBm. More negative values indicate a weaker received signal.

THRUST		THRUST	
↑ 120 m		↑ 120 m	
⊙ 42 m/s		⊙ 42 m/s	
↖ 46.0050 N	▶	↖ 46.0050 N	▶
↘ 8.0075 E	▶	↘ 8.0075 E	▶
🔋 4.1 V	1✓2✓	🔋 4.1 V	1✓2✓
AGE 0.0	SNR 9	AGE 0.0	SNR 7
LQ 98	RSSI -52	LQ 94	RSSI -58

(a) GNSS telemetry from both receivers in Single mode.

THRUST		THRUST	
↑ 120 m		↑ 120 m	
⊙ 42 m/s		⊙ 42 m/s	
↖ 54 m	◀	↖ 54 m	◀
⊙ 54.8°	◀	⊙ 54.8°	◀
🔋 4.1 V	1✓2✓	🔋 4.1 V	1✓2✓
AGE 0.0	SNR 9	AGE 0.0	SNR 7
LQ 98	RSSI -52	LQ 94	RSSI -58


(b) Relative downrange distance and direction.

Figure 11: Ground Station Live views

5.2.1.2 Recovery

The Recovery screen guides you toward the last valid GNSS position received from the rocket. It shows the selected rocket, distance, relative direction, and whether a usable location is available. Calibrate the Ground Station compass outdoors near the launch site and away from large metal objects before relying on direction guidance.

In Dual receiver mode, press Up or Down to choose Link 1 or Link 2. Press Right to show a QR code for the selected last location; scan it with a phone to open the coordinates in a mapping application. If the other link also has a valid location, press Right again to switch QR-code pages. Press Left to return to direction guidance.



(a) Direction and distance to the last received location.



(b) QR code for transferring the selected last location.

Figure 12: Ground Station Recovery views

5.2.1.3 Testing


The Testing screen arms testing mode and manually triggers configured flight events. Triggered events execute their assigned actions. Read Section 8 completely before using this screen.

5.2.1.4 Data

The Data screen lists logs stored on the Ground Station. An active recording is marked as active. Select a log to view its duration, maximum altitude and velocity, flight state, and recorded locations. When a valid location is available, open its QR-code page to transfer the coordinates to a phone.



The options page can finalize the active log or delete a completed log after confirmation. Disconnect the Ground Station USB drive before deleting a log. Finalizing stops the active recording and closes its files; deleting permanently removes the selected completed log.



(a) Select a stored Ground Station flight log.


(b) Review recorded statistics and last locations.

Figure 13: Ground Station Data views

5.2.1.5 Sensors

The Sensors screen shows raw IMU, magnetometer, and GNSS readings. Press Right or Down to open the Compass / 3D Orientation page, which shows the Ground Station's heading, pitch, and roll. Press Left or Up to return to raw readings.

Press A to start compass calibration and follow the on-screen instructions. Rotate the Ground Station slowly through multiple orientations, away from large metal objects and magnets. When calibration reaches 100%, confirm the result to save it.



(a) Raw IMU, magnetometer, and GNSS readings.

(b) Compass heading, pitch, and roll.

Figure 14: Ground Station Sensors views

5.2.1.6 Settings


Settings are divided into three pages. Move Left or Right while no setting is selected to change pages.

Page	Setting	Purpose
Telemetry	Receiver Mode	Single uses both receivers for one Vega; Dual assigns one Vega to each receiver.
Telemetry	Link Phrase 1	Phrase used by both receivers in Single mode or the left receiver in Dual mode.
Telemetry	Link Phrase 2	Phrase used by the right receiver in Dual mode.
Telemetry	Test Phrase	Phrase required to arm Vega testing mode.




Preferences	Stop Logging	Stop at landing or continue until manually finalized.
Preferences	Time Zone	Local offset from UTC.
Preferences	Units	Metric or imperial display units; recorded data remains metric.
Preferences	Startup Animation	Animated startup or static CATS logo.
System	Firmware Versions	Ground Station and both receiver-firmware versions.
System	USB Drive	View or disconnect the shared USB storage.
System	Self-Test	Factory-oriented automatic and guided hardware checks.
System	Update Firmware	Update the Ground Station application or both radio receivers.

Table 8: Ground Station settings



(a) Telemetry settings.



(b) Display and recording preferences.

Figure 15: Ground Station Telemetry and Preferences settings




Figure 16: Ground Station System settings

5.2.2 Telemetry Modes

The Ground Station's telemetry settings include a *mode* option. Because the Ground Station has two receivers, it supports two modes.

In **Dual mode**, the Ground Station can track two Vega flight computers. This is useful when a section separates from the rocket and you want to track it as well as the main body.



In **Single mode**, the Ground Station tracks one Vega flight computer. Packets from both receivers are combined, allowing more data to be received than with a single receiver. For best diversity performance, use one directional antenna and one omnidirectional antenna.

5.2.3 Data Streaming via USB

When connected to a computer via USB, the Ground Station continuously streams each newly received telemetry packet through its virtual serial port. Each line identifies the radio link and includes the timestamp, flight state, GPS coordinates, altitude, velocity, and battery voltage; in dual-receiver mode, data from both links is reported.

The serial stream emits one line per newly received telemetry packet. All units are fixed and are not affected by the Ground Station's unit settings:

- **Link:** Receiving radio link number (1 or 2)
- **Ts:** Flight-computer uptime in seconds, with 0.1 s resolution
- **State:** Numeric flight state (0–7: Invalid, Calibrating, Ready, Thrusting, Coasting, Drogue, Main, Touchdown)
- **Lat / Lon:** GPS coordinates in decimal degrees
- **Alt:** Estimated altitude in meters
- **Vel:** Estimated vertical velocity in meters per second
- **V:** Flight-computer battery voltage in volts, with 0.1 V resolution

```
COM3 - Tera Term VT
File Edit Setup Control Window Help
===== CATS Ground Station =====
Link 1: Ts: 75.3, State: 2, Lat: 0.00000, Lon: 0.00000, Alt: 0, Vel: 0, U: 0.2
Link 1: Ts: 75.4, State: 2, Lat: 0.00000, Lon: 0.00000, Alt: 0, Vel: 0, U: 0.2
Link 2: Ts: 75.5, State: 2, Lat: 0.00000, Lon: 0.00000, Alt: 0, Vel: 0, U: 0.2
Link 1: Ts: 75.6, State: 2, Lat: 0.00000, Lon: 0.00000, Alt: 0, Vel: 0, U: 0.2
Link 1: Ts: 75.7, State: 2, Lat: 0.00000, Lon: 0.00000, Alt: 0, Vel: 0, U: 0.2
Link 1: Ts: 75.8, State: 2, Lat: 0.00000, Lon: 0.00000, Alt: 0, Vel: 0, U: 0.2
Link 1: Ts: 75.9, State: 2, Lat: 0.00000, Lon: 0.00000, Alt: 0, Vel: 0, U: 0.2
Link 1: Ts: 76.0, State: 2, Lat: 0.00000, Lon: 0.00000, Alt: 0, Vel: 0, U: 0.2
Link 1: Ts: 76.1, State: 2, Lat: 0.00000, Lon: 0.00000, Alt: 0, Vel: 0, U: 0.2
Link 1: Ts: 76.2, State: 2, Lat: 0.00000, Lon: 0.00000, Alt: 0, Vel: 0, U: 0.2
Link 1: Ts: 76.3, State: 2, Lat: 0.00000, Lon: 0.00000, Alt: 0, Vel: 0, U: 0.2
Link 1: Ts: 76.4, State: 2, Lat: 0.00000, Lon: 0.00000, Alt: 0, Vel: 0, U: 0.2
Link 1: Ts: 76.5, State: 2, Lat: 0.00000, Lon: 0.00000, Alt: 0, Vel: 0, U: 0.2
Link 1: Ts: 76.6, State: 2, Lat: 0.00000, Lon: 0.00000, Alt: 0, Vel: 0, U: 0.2
Link 1: Ts: 76.7, State: 2, Lat: 0.00000, Lon: 0.00000, Alt: 0, Vel: 0, U: 0.2
Link 1: Ts: 76.8, State: 2, Lat: 0.00000, Lon: 0.00000, Alt: 0, Vel: 0, U: 0.2
Link 1: Ts: 76.9, State: 2, Lat: 0.00000, Lon: 0.00000, Alt: 0, Vel: 0, U: 0.2
Link 1: Ts: 77.0, State: 2, Lat: 0.00000, Lon: 0.00000, Alt: 0, Vel: 0, U: 0.2
Link 2: Ts: 77.1, State: 2, Lat: 0.00000, Lon: 0.00000, Alt: 0, Vel: 0, U: 0.2
Link 2: Ts: 77.2, State: 2, Lat: 0.00000, Lon: 0.00000, Alt: 0, Vel: 0, U: 0.2
Link 2: Ts: 77.3, State: 2, Lat: 0.00000, Lon: 0.00000, Alt: 0, Vel: 0, U: 0.2
Link 2: Ts: 77.4, State: 2, Lat: 0.00000, Lon: 0.00000, Alt: 0, Vel: 0, U: 0.2
Link 2: Ts: 77.5, State: 2, Lat: 0.00000, Lon: 0.00000, Alt: 0, Vel: 0, U: 0.2
Link 2: Ts: 77.6, State: 2, Lat: 0.00000, Lon: 0.00000, Alt: 0, Vel: 0, U: 0.2
Link 2: Ts: 77.7, State: 2, Lat: 0.00000, Lon: 0.00000, Alt: 0, Vel: 0, U: 0.2
Link 2: Ts: 77.8, State: 2, Lat: 0.00000, Lon: 0.00000, Alt: 0, Vel: 0, U: 0.2
Link 2: Ts: 77.9, State: 2, Lat: 0.00000, Lon: 0.00000, Alt: 0, Vel: 0, U: 0.2
Link 2: Ts: 78.0, State: 2, Lat: 0.00000, Lon: 0.00000, Alt: 0, Vel: 0, U: 0.3
Link 2: Ts: 78.1, State: 2, Lat: 0.00000, Lon: 0.00000, Alt: 0, Vel: 0, U: 0.2
Link 2: Ts: 78.2, State: 2, Lat: 0.00000, Lon: 0.00000, Alt: 0, Vel: 0, U: 0.2
Link 2: Ts: 78.3, State: 2, Lat: 0.00000, Lon: 0.00000, Alt: 0, Vel: 0, U: 0.2
Link 2: Ts: 78.4, State: 2, Lat: 0.00000, Lon: 0.00000, Alt: 0, Vel: 0, U: 0.2
Link 2: Ts: 78.5, State: 2, Lat: 0.00000, Lon: 0.00000, Alt: 0, Vel: 0, U: 0.2
Link 2: Ts: 78.6, State: 2, Lat: 0.00000, Lon: 0.00000, Alt: 0, Vel: 0, U: 0.2
Link 2: Ts: 78.7, State: 2, Lat: 0.00000, Lon: 0.00000, Alt: 0, Vel: 0, U: 0.2
Link 2: Ts: 78.8, State: 2, Lat: 0.00000, Lon: 0.00000, Alt: 0, Vel: 0, U: 0.2
```

Figure 17: Ground Station telemetry data from both radio links streamed over the USB serial port.



5.2.4 Charging

The Ground Station is powered by a Li-ion 18650 battery. A fully charged battery provides more than 8 hours of operation. Charge the battery through the USB port. At a charging current of 500 mA, a full charge can take up to 6 hours. The LED next to the USB port lights while the battery is charging and turns off when charging is complete. To replace the internal battery, remove the battery cover on the back of the Ground Station. If the replacement battery has different specifications, the estimated remaining charge shown on the screen may differ from the actual percentage.

5.2.5 How to Get the Data on Your Computer

When connected by USB and not actively recording, the Ground Station shares its data partition as the **CATS GS** USB drive. Open the drive and copy the required **.csv** logs to the computer. The firmware reclaims the filesystem automatically when recording starts and shares it again after the log is finalized. Close files before recording or updating firmware, and use **Settings** → **System** → **USB Drive** when the drive needs to be disconnected manually.

5.2.6 Software Updates

Use the Configurator's Firmware Updates page for normal Ground Station and radio-receiver updates. See Section 6 for the complete preparation, installation, verification, and recovery procedures.



6 Firmware Updates

The Configurator installs official stable firmware for the CATS Vega and Ground Station. It also prepares the firmware file that the Ground Station uses to update both of its radio receivers. Use the Firmware Updates page instead of downloading files and selecting programming tools manually.

Normal firmware installation is supported on Windows. On Linux and macOS, the Configurator can check connected devices and releases, but the standard release keeps flashing disabled until those USB workflows have completed hardware acceptance.

6.1 Before Updating

1. Install the latest Configurator from the Configurator releases page⁴. The Firmware Updates page updates connected CATS devices; it does not update the Configurator application itself.
2. Save or discard any unsaved configuration changes. Firmware installation is disabled while the Configurator contains unsaved changes.
3. Connect only the device that you intend to update. Disconnect deployment charges and place the Vega safely on the bench. Stop Ground Station tracking and recording, and close any files opened from its USB drive.
4. Keep the device powered and connected until the Configurator or Ground Station reports that verification has completed.

Warning: Never update a Vega with deployment charges or other energetic outputs connected. Do not reset, unplug, or power off a device while firmware is being written or verified.

6.2 Updating the Configurator

Download the current installer from the Configurator releases page, close the running Configurator, and run the installer. After installation, open the Configurator and confirm the expected **App version** in the footer.

⁴<https://github.com/catsystems/cats-configurator/releases>




Figure 18: Configurator Firmware Updates page after a successful device and release check

6.3 Updating the CATS Vega

1. Connect the Vega by USB, open **Firmware Updates**, and select **Check devices & releases**.
2. In the Vega panel, verify the detected device, installed version, and available version. Select **Update Vega**.
3. Confirm that deployment charges are disconnected. If the installed version is unknown or the same version is being reinstalled, acknowledge the additional confirmation shown by the Configurator.
4. Select **Start update**. The Configurator downloads and validates the official image, moves the Vega into its native USB DFU bootloader, erases and writes the application, reads it back for verification, and starts the new firmware.
5. Leave USB connected while the Vega reconnects. The update is complete only after the Configurator verifies the running firmware version.

The Configurator prevents cancellation after the device starts transitioning into its bootloader. If the application reports a failed verification or reconnect step, leave the Vega connected and use the offered retry action. STM32CubeProgrammer and an ST-Link debugger are service and recovery tools, not part of the normal update procedure.

6.4 Updating the Ground Station

1. Connect the Ground Station through its normal USB port. Stop tracking and recording, and close all files on the CATS GS drive.
2. Open **Firmware Updates**, select **Check devices & releases**, and verify the Ground Station detected from its `version.json` information.



3. Select **Update Ground Station**, confirm the safety prompt, and start the update. Keep the Ground Station connected while the Configurator enters TinyUF2, copies the official `.uf2` image, and waits for the application to return.
4. The update is complete only when the Configurator reads a fresh `version.json` and reports the installed version.

If automatic bootloader entry is unavailable, use **Settings** → **System** → **Update Firmware** → **Ground Station** on the device. Then return to the Configurator, check devices again, and start or retry the update. Do not use a 1200-baud reset; on this hardware it enters the ESP32 ROM bootloader rather than the supported TinyUF2 update path.

6.5 Updating the Ground Station Radio Receivers


The Configurator validates and copies the radio image, while the Ground Station performs the installation on both receiver modules.

1. Connect the normal CATS GS USB drive, open **Firmware Updates**, and select **Check devices & releases**.
2. In the Ground Station radios panel, verify the detected drive and available version. Select **Prepare radio firmware** and confirm that tracking, recording, and file access have stopped.
3. After preparation succeeds, close all files and safely eject the CATS GS drive from the computer.
4. On the Ground Station, open **Settings** → **System** → **Update Firmware** → **Radio Receivers**.
5. Select the prepared `.bin` file from the `telemetry_firmware` directory and confirm the update. Keep the Ground Station powered while it updates and verifies both radios.
6. Do not leave the update screen until it reports **Both radios verified** and shows the expected version for Link 1 and Link 2.
7. Power-cycle the Ground Station, reconnect its normal USB drive, and select **Check devices & releases** in the Configurator to refresh all reported versions.


Note: A completed file-copy progress bar means only that the radio image was prepared. It does not mean that either receiver was updated. Installation and verification take place on the Ground Station.

Compatibility: Telemetry receiver firmware 1.2.0 is the first version that can enter this updater. Receivers running version 1.1.3 or earlier require a one-time ST-Link installation of version 1.2.0 or newer. If a receiver cannot enter the updater, the Ground Station stops before erasing or writing it. Restart the Ground Station before another update attempt.


The following Ground Station screens show the complete on-device sequence. Filenames, versions, sizes, and checksums are examples; use the file and version prepared by your Configurator.




(a) Open Update Firmware from the System settings page.




(b) Select Radio Receivers.




(c) Select the prepared radio image.



(d) Confirm the selected image and keep power connected.



(e) Wait while each receiver is written and verified.



(f) Confirm that both radios were verified.

Figure 19: Ground Station radio-receiver update sequence

6.6 Recovering an Interrupted Update

Keep the device connected and follow the retry action shown by the Configurator. A Vega that remains in native DFU can be written and verified again. A Ground Station already in TinyUF2 can be checked again before retrying the validated update. If a radio update was interrupted, reopen the Ground Station's Radio Receivers update screen and run the prepared file again, then verify both reported versions.

If a device cannot enter its supported bootloader or cannot be detected after the documented retries, disconnect all outputs and contact CATS support. Direct programming through STM32CubeProgrammer or an ST-Link debugger is reserved for service recovery and factory provisioning.



7 Example Configurations

These examples show how hardware, flight events, actions, and timers fit together. Adapt all thresholds, deployment altitudes, delays, and output settings to the actual rocket and recovery system.

Warning: The values below are examples, not flight-ready recommendations. Verify the complete configuration in **Preflight** and test every recovery mechanism safely before flight.

7.1 Simple Dual-Deployment Example

This example uses a pyrotechnic charge on Pyro Channel 1 for the drogue parachute and a second charge on Pyro Channel 2 for the main parachute.

Area	Example value	Purpose
Configuration	Liftoff threshold: $40 \frac{m}{s^2}$	Detect liftoff after the configured acceleration is sustained.
Events & Timers	Apogee → Pyro 1 ON	Deploy the drogue parachute at detected apogee.
Events & Timers	Main Deployment → Pyro 2 ON	Deploy the main parachute below the configured main altitude.
Events & Timers	Timer: Liftoff → Apogee after 15 s	Provide a time-based backup for the apogee event.

Table 9: Simple dual-deployment example

Connect the battery and switch, then connect the deployment circuits to Pyro Channels 1 and 2 as shown below. Keep the charges disconnected while checking continuity and event behavior.




Figure 20: CATS Vega with a battery, switch, Pyro 1 and Pyro 2 connected.

In **Preflight**, verify the main-deployment altitude, liftoff threshold, timer, event sequence, and both pyro actions. Use the procedure in Chapter 8 to test the configuration with safe substitutes before connecting energetic devices.

7.2 Advanced Recovery Example

This example adds timed actions, a servo-deployed main parachute, a camera, and a low-level output. It illustrates the available building blocks; it is not a recommended configuration for a specific vehicle.



Area	Example value	Purpose
Configuration	Liftoff threshold: $40 \frac{m}{s^2}$	Detect liftoff.
Configuration	Main altitude: 350 m	Trigger the Main Deployment event below 350 m during descent.
Configuration	Servo 1 initial position: mechanism closed	Hold the main-deployment mechanism in its safe initial position. Determine the actual value on the bench.
Events & Timers	Apogee → Pyro 1 ON; delay 2 s; Pyro 1 OFF	Operate a solenoid valve for two seconds.
Events & Timers	Main Deployment → Servo 1 deployed position	Open the main-deployment mechanism. Determine the deployed value on the bench.
Events & Timers	Liftoff → Pyro 2 ON; Touchdown → Pyro 2 OFF	Control an externally powered camera through a suitable interface.
Events & Timers	Burnout → I/O ON	Assert the low-level output at burnout.
Events & Timers	Timer: Liftoff → Apogee after 45 s	Provide a time-based backup for the apogee event.

Table 10: Advanced recovery example

Connect the battery and switch, the solenoid-valve interface to Pyro Channel 1, the camera interface to Pyro Channel 2, and the main-deployment mechanism to Servo Channel 1 as shown below. Observe the electrical limits in Section 4.1 and use external drivers where the load requires them.




Figure 21: CATS Vega with a battery, switch, solenoid valve, camera, and servo connected.

Before flight, use **Preflight** to inspect the complete timeline, including delayed actions and timer-triggered events. Test each event individually in testing mode, then disable testing mode, reboot the Vega, and run Preflight again.



8 Testing

Testing mode lets you trigger the Vega's configured events from a Ground Station while the system is secured on the bench.

8.1 What Testing Mode Does

Testing mode stops normal flight-state processing. After the Vega and Ground Station enter armed testing mode, the Ground Station can trigger any configured event. Every action assigned to that event is executed, including pyrotechnic, servo, low-level I/O, recorder, and delayed actions.

Warning: Treat every configured output as live. Remove motors and energetic charges until you intentionally test that output, secure the hardware, and keep people clear of all deployment mechanisms. Never fly in testing mode.


Note: Unlike during flight, an event can be triggered repeatedly without rebooting. The Vega leaves armed testing mode if the telemetry link is lost.

8.2 Before You Start


- Secure the Vega, battery, Ground Station, and every connected mechanism on a suitable test bench.
- Disconnect pyrotechnic charges, motors, and other energetic devices unless testing them is the specific purpose of the procedure.
- In the Configurator, review **Events & Timers** and confirm every action that will run for each event.
- Open **Preflight** and resolve every reported configuration or connection problem.
- Confirm that the Vega and Ground Station use the same receiver mode, link phrase, and testing phrase.

8.3 Enabling and Using Testing Mode


1. Connect the Vega to the computer and open the Configurator. The Configurator connects automatically when exactly one compatible Vega is available; otherwise, select it manually.
2. Open **Configuration**, enable **Testing Mode**, and set a testing phrase. Save the configuration.
3. Reboot the Vega. Testing mode does not become active until after the reboot.
4. Confirm that the Vega emits the **Testing** beeping pattern described in Section 4.4 .
5. Turn on the Ground Station. In **Settings** → **Telemetry**, select the matching receiver mode and set **Link Phrase 1** and **Test Phrase** to the values configured on the Vega.
6. Open **Testing** on the Ground Station. Read the safety notice, press the A button to continue, and wait for the Ground Station to arm the Vega.
7. Confirm that the Vega emits the **Armed Testing** beeping pattern.
8. Select an event, review the confirmation screen, and confirm only when the test area is clear. Observe every configured output and delayed action.
9. Repeat only the checks required for the test. If the telemetry link is lost, return to the Testing menu and arm the system again.




(a) Read the complete safety notice.



(b) Continue only when the connected Vega is in testing mode.



(c) Wait while the Ground Station arms the Vega.



(d) Select the configured event to test.

Figure 22: Entering testing mode and selecting an event




Figure 23: Final confirmation before triggering the selected event

8.4 Returning to Flight Configuration

1. Exit **Testing** on the Ground Station.
2. Reconnect the Vega to the Configurator, disable **Testing Mode**, and save the configuration.
3. Reboot the Vega and confirm that the Testing beep pattern is no longer emitted.
4. Run **Preflight** again before installing energetic devices or preparing the rocket for flight.

Warning: Testing mode manually executes the actions assigned to the selected event. CATS GmbH is not responsible for injuries or material damage caused by unsafe manual operation of the CATS System.



9 Advanced Information

This section explains the core components of the CATS Vega board in greater detail. It is intended for advanced users.

9.1 Software Overview

This section provides a brief overview of the software architecture. It is intended for advanced users with some programming experience; understanding it is not required to use the flight computer. The software is implemented in C++ and uses FreeRTOS as its foundation. The hardware is initialized first, after which the tasks are started. Figure 24 shows the running tasks.




Figure 24: Illustration of the different FreeRTOS tasks interacting with each other and the hardware. The black circle 'Settings' is just a memory region that is being accessed by different tasks.

The following list briefly describes each task.

- **Sensor Read** reads the Barometer and IMU data and provides it to the Preprocessing task.
- **Preprocessing** converts the raw barometric pressure to altitude above ground level and the linear acceleration to acceleration in the "up" direction. It provides the processed data to the FSM and State Estimation tasks.
- **State Estimation** estimates the current height and velocity based on the Preprocessing task's output and the FSM state.
- **FSM** computes the current flight phase from the State Estimation and Preprocessing outputs.
- **Transceiver** handles communication between the main chip and the telemetry chip.
- **USB Communicator** is a group of three tasks that handle the interface between the flight computer and the user's computer. These tasks do not start when USB is not connected.
- **Peripherals** triggers all user-defined events.
- **Health Monitor** checks values like the buzzer and the battery voltage.
- **Recorder** uses a queue to record all data to the flash chip.
- **Buzzer** actuates the buzzer.



9.2 Telemetry

The telemetry system uses 2.4 GHz LoRa and FHSS (Frequency-Hopping Spread Spectrum). FHSS makes transmissions more resistant to interference and more difficult to intercept. It also allows more devices to use the same frequency band with little or no effect on link quality.

Hopping Pattern

The link phrase defines the hopping pattern. It is hashed with a CRC-32 algorithm, and the resulting value seeds a pseudo-random number generator. The generator runs 20 times to define the hopping pattern. As a result, a given link phrase always produces the same pattern. The transmitter and receiver must use the same link phrase to communicate.




Figure 25: FHSS transmission example

Synchronization

The receiver waits on the first frequency until it receives a synchronization packet. This packet contains the link CRC, which identifies the transmission source. If the remote CRC matches the local value, the receiver hops to the next frequency and waits for data. Each data packet contains a checksum for validating its contents. The receiver measures the interval between packets and hops to the next frequency when a packet is not received within the estimated interval. It can perform 30 hops without receiving a packet before synchronization is lost. If the connection is lost, the receiver returns to the first frequency.



9.3 Estimation Algorithms

State estimation calculates the rocket's velocity and altitude from barometric pressure and linear acceleration in the z direction.

Calibration of Sensors

Linear acceleration is calibrated when the system enters the Ready state. This allows the flight computer to be mounted in any orientation. The gravity vector is used to calculate the up direction, which is then used throughout the flight.

Warning: Power up the flight computer only after the rocket is upright on the launch pad. To prevent repeated transitions into and out of the Ready state, calibration is performed only once, as soon as no motion is detected after startup.

During Calibrating and Ready, the current altitude above sea level is continuously estimated. Altitude above ground level, the value used during flight, is calculated from the altitude above sea level. This calculation assumes that barometric pressure changes very slowly. When Liftoff is detected, the altitude above sea level is fixed, and only the altitude above ground level is updated.

Kalman Filter

A Kalman Filter estimates altitude and velocity from the calibrated values. Its derivation is described below. We define the state and noise as

$$x(t) = \begin{pmatrix} h(t) \\ v(t) \\ a_o(t) \end{pmatrix} \quad v = \begin{pmatrix} v_1 \\ v_2 \end{pmatrix}$$

where h is the altitude above ground level, v is the vertical velocity, and a_o is the estimated offset of the measured vertical acceleration. v_1 is the noise applied to the vertical acceleration, and v_2 is the noise used to estimate the linear-acceleration offset.

The system input is $u(t)$, the linear acceleration measured in the z direction.

$$\dot{x}(t) = \begin{pmatrix} \dot{v}(t) \\ \dot{a}(t) \\ \dot{a}_o(t) \end{pmatrix} = A \cdot x(t) + B \cdot u(t) + G \cdot v(t) = \begin{pmatrix} 0 & 1 & 0 \\ 0 & 0 & 1 \\ 0 & 0 & 0 \end{pmatrix} \cdot \begin{pmatrix} h(t) \\ v(t) \\ a_o(t) \end{pmatrix} + \begin{pmatrix} 0 \\ 1 \\ 0 \end{pmatrix} \cdot u(t) + \begin{pmatrix} 0 & 0 \\ 1 & 0 \\ 0 & 1 \end{pmatrix} \cdot \begin{pmatrix} v_1(t) \\ v_2(t) \end{pmatrix}$$

This is discretized using a first-order approximation:

$$A_d = e^{AT_s} \quad B_d = \int_0^{T_s} e^{A_d t} \delta t \cdot B \quad G_d = \int_0^{T_s} e^{A_d t} \delta t \cdot G$$

which gives the system

$$x(k+1) = A_d \cdot x(k) + B_d \cdot u(k) + G_d \cdot v(k)$$

The process measurement noise matrix becomes

$$Q(k) = \begin{pmatrix} Q_{acc}(k) & 0 \\ 0 & Q_{acc_0}(k) \end{pmatrix}$$

The measurement step assumes that altitude has already been calculated from barometric pressure using the standard barometric formula.



$$z(k) = h_{\text{meas}}(k) + \omega(k) = \left(\frac{p(k)^{\frac{1}{5.257}}}{p_0} - 1 \right) \cdot \frac{T_0 + 273.15}{L} - h_0 + \omega(k)$$

where $L = -0.0065$, $T_0 = 15$ C, $p_0 = 101250$ Pa, h_0 is the calibrated altitude above sea level, and ω is the measurement noise.

The measurement function is

$$z(k) = H \cdot x(k) = (1 \ 0 \ 0) \cdot \begin{pmatrix} h(k) \\ v(k) \\ a_o(k) \end{pmatrix}$$

The measurement-noise matrix becomes a scalar:

$$R(k) = R_{\text{height}}$$

The standard Kalman-filter equations can then propagate the state.

Gain Scheduling

Gain scheduling reduces reliance on the barometer during high-velocity flight, because barometric measurements can behave unpredictably in the transonic regime.

At Liftoff and while the rocket is moving quickly, the accelerometer is weighted more heavily when estimating altitude and velocity. At lower velocities, barometric pressure is weighted more heavily because accelerometer drift affects the estimate. As the rocket arcs over, the quality of the accelerometer measurement also decreases.

Two variables control the relative trust in the sensors: Q_{acc} and R_{height} . In the algorithm, Q_{acc} remains constant, while R_{height} changes during flight. The conditions for changing R_{height} are shown below.

$$R_{\text{height}} = \begin{cases} R_{\text{initial}} & \text{for state = MOVING or IDLE} \\ R_{\text{max}} & \text{for state = LIFTOFF} \\ R_{\text{max}} \cdot f(v) & \text{for state = COASTING} \\ R_{\text{initial}} & \text{otherwise} \end{cases}$$

where $f(v)$ depends on the current velocity.

This gain scheduling effectively filters unexpected barometric measurements at high velocities.



9.4 Using the Python Plotting Tool

For more control over flight data, use the legacy Python plotting tool. It provides the Configurator's plotting functionality in a form that is easier to customize.

To visualize logs recorded by the Vega flight computer, clone the cats-logs repository and run the log_visualizer.py script. Git and Python 3 must be installed to download and run the script.

To visualize your logs, follow these steps:

```
git clone https://github.com/catsystems/cats-logs.git
cd cats-logs/log_parsing
pip install -r requirements.txt
python log_visualizer.py -i <path to input log> -o <path to output directory>
```

The script parses the log file and generates a self-contained HTML file containing all plots. It also generates raw and processed CSV files for each type of recorded value.

For more information about the visualizer script, run:

```
./log_visualizer.py --help
```



9.5 Common CLI Commands

The CLI is intended for advanced inspection, recovery, and configuration. To access it, connect the Vega through the Configurator and open **CLI**. The commands and parameters below are the most useful ones; run **help** for the authoritative list provided by the connected firmware. Square brackets [] indicate an optional argument, while angle brackets < > identify a parameter name.

After changing configuration values, run **save** and verify the result with **config**.

bl	Put the board into DFU mode	For advanced recovery. Normal firmware updates use the Configurator workflow in Chapter 6 .
cd	Change the current working directory	
config	Print the flight config in a human-readable format	
defaults [-no-outputs]	Reset to default settings	The default configuration triggers pyro channels. If -no-outputs is passed, pyro triggering is not configured.
dump	Print configurable settings in a readable format	
flash_erase	Erase everything on the flash chip; this might take a while	
flash_test	Test writing to and reading from the flash	For testing purposes only; do not use
flash_start_write	Start writing to flash	For testing purposes only; do not use
flash_stop_write	Stop writing to flash	For testing purposes only; do not use
flight_dump <flight_number>	Print a specific flight in binary format	
flight_parse <flight_number>	Print a specific flight in a human-readable format	
get [command_name]	Get a variable value, described in Table 13	
help [search string]	Display all commands with a description	
lfs_format	Reformat the flash filesystem	
log_enable	Enable log output on the terminal	
ls	List all files in the current working directory	
reboot	Reboot the flight computer	This command does not save the changed settings by itself
rec_info	Get information about flash usage	
rm <file_name>	Remove a file	
save	Save flight configuration	



set [<command_name>=<value>]	Set a variable, described in Table 13	
stats <flight_number>	Print flight statistics	
status	Show current sensor data, flight phase, and other important information	
version	Show the firmware version	

Table 11: Common CLI commands

9.5.1 Common Configuration Parameters

The variables below can be read with the **get** command or changed with the **set** command. Changes are saved to the flight computer's configuration only after the **save** command is run.

acc_threshold	Acceleration threshold above which liftoff is detected	
main_altitude	Altitude above ground level under which main deployment is triggered	
timer1_start	Event which triggers timer 1	
timer1_trigger	Event which is triggered once timer 1 elapses	
timer1_duration	Timer 1 duration	
timer2_start	Event which triggers timer 2	
timer2_trigger	Event which is triggered once timer 2 elapses	
timer2_duration	Timer 2 duration	
timer3_start	Event which triggers timer 3	
timer3_trigger	Event which is triggered once timer 3 elapses	
timer3_duration	Timer 3 duration	
timer4_start	Event which triggers timer 4	
timer4_trigger	Event which is triggered once timer 4 elapses	
timer4_duration	Timer 4 duration	
ev_calibrate	Set the actions associated with the calibration event	Do not use!
ev_ready	Set the actions associated with the ready event	Do not use!
ev_liftoff	Set the actions associated with the liftoff event	Prefer the Configurator's Events & Timers page.
ev_burnout	Set the actions associated with the burnout event	Do not use!
ev_apogee	Set the actions associated with the apogee event	Do not use!
ev_main_deployment	Set the actions associated with the main deployment event	Do not use!



ev_touchdown	Set the actions associated with the touchdown event	Do not use!
ev_custom1	Set the actions associated with the custom 1 event	Do not use!
ev_custom2	Set the actions associated with the custom 2 event	Do not use!
servo1_init_pos	Set the initial position of servo 1	
servo2_init_pos	Set the initial position of servo 2	
tele_link_phrase	Set the telemetry link phrase	
tele_test_phrase	Set the testing phrase	
tele_power_level	Set the telemetry power level	
tele_enable	Enable or disable telemetry	
tele_adaptive_power	Enable or disable adaptive power for the telemetry power level	Adaptive power mode boosts output power to maximum when the flight computer is in <i>THRUSTING</i> mode and returns it to the user-set value when <i>TOUCHDOWN</i> is registered.
buzzer_volume	Set the buzzer volume	
battery_type	Set the battery type used with the CATS Vega	
rec_elements	Set the desired recorded elements	A bit mask corresponding to the rec_entry_type_e enum
rec_speed	Set the desired sampling period for recording	
test_mode	Enable or disable testing mode	A reboot is required after saving the change.

Table 12: Common parameters used with the **get** and **set** commands



10 FAQ and Troubleshooting

The Configurator does not find my Vega

Use a USB data cable and connect the Vega directly to the computer. If more than one compatible device is connected, select the intended device manually. Use the refresh button in the device selector after reconnecting the cable. On Windows, also check whether another application has opened the same serial port.

My configuration changes disappear after reconnecting

Select **Save** before disconnecting or rebooting the Vega. After saving, use **Refresh** or reconnect and confirm that the stored values match the intended configuration. Run **Preflight** before flight.

The Ground Station does not receive telemetry

Confirm that telemetry is enabled on the Vega, both devices have antennas attached, and the Ground Station receiver mode and link phrase match the Vega configuration. In Single mode, Link Phrase 1 is used by both receivers; in Dual mode, each receiver has its own phrase. Check the Ground Station's **Firmware Versions** page if only one receiver behaves unexpectedly.

Testing mode does not arm

Enable testing mode and set a valid testing phrase in the Configurator, save the configuration, and reboot the Vega. Set the same Test Phrase and receiver mode on the Ground Station. The Vega must emit the Testing beep pattern before the Ground Station can arm it. See Chapter 8 for the complete safety procedure.

A flight or Ground Station log is missing

Vega flight logs can be opened from the Configurator's **Flight Logs** page, including logs still stored onboard. Ground Station logs are exposed on the **CATS GS** USB drive; finalize an active log before copying it, and use **Settings** → **System** → **USB Drive** before disconnecting the cable.

A firmware update was interrupted

Reconnect the device and start the update again using the recovery procedure in Chapter 6 . After any update, reconnect and verify the reported version before using the device. Normal Vega firmware installation from the Configurator is supported on Windows.

GNSS position is unavailable or inaccurate

Move the Vega and Ground Station outdoors with a clear view of the sky, keep antennas away from large conductive objects, and allow time for a fix. Do not rely on the last displayed coordinates until the Ground Station shows a current fix.

If the problem remains, collect the device and firmware versions, describe the exact steps taken, and contact us on our Discord server or open an issue in the relevant CATS repository.