

Venture XL

Installation and Operation Instruction

☆ Please refer to this guide to complete the installation of this device.



Entrust your imagination to the 3D printer. With one-click start, explore the new field of 3D printing and obtain practical results beyond expectations.



Dear friends,

When you start using this device, ensuring electrical safety is the first prerequisite.

The operation of the device involves a complex circuit system. Any illegal operation of electricity may cause equipment failure, electrical accidents, and endanger the safety of personnel and property. Please read the entire manual before starting assembly and before starting the device carefully check the electrical connections of the device to lay a solid foundation for the smooth use of the device.

Please check our Discord channels for any tips and questions that may halt your progress.

Most of all, good luck!

REPORTING ISSUES



Should you find an issue in the documentation or have a suggestion for an improvement please consider opening an issue on GitHub (https://github.com/FYSETC/Venture_XL). When raising an issue please include the relevant page numbers and a short description; annotated screenshots are also very welcome. We periodically update the manual based on the feedback we get.

THIS IS JUST A REFERENCE

This manual is designed to be a simple reference manual. Building a Venture_XL can be a complex endeavour and for that reason we recommend downloading the CAD files off our Github repository if there are sections you need clarification on. It can be sometimes be easier to follow along when you have the whole assembly in front of you.

GitHub



https://github.com/FYSETC/Venture_XL



BLIND JOINT BASICS



Blind Joints provide a cost effective and rigid assembly method.


The head of the BHCS is slid into the channel of another extrusion and securely fastened through a small access hole in the extrusion.



FRAME

WWW.FYSETC.COM






SORT EXTRUSIONS

Collect your extrusions and sort them by length. We will highlight the extrusions used in each step and label them as shown on this page.

FRAME

WWW.FYSETC.COM



PREPARE 8 EXTRUSIONS


- Prepare the first 8 aluminum profiles that will be used in this section;
- Prepare them as shown above, screw the 6Pcs M5x12 BHCS into the aluminum profile, do not tighten.

FRAME



FRAME ASSEMBLY

This design relies on blind joints to assemble the frame. We outlined the basics of blind joints on page 4.

More tips on how to assemble a frame are linked below.



WWW.FYSETC.COM



BUILD ON A FLAT SURFACE



- Build the frame on a flat surface (build the frame on glass or granite surface) to ensure you get as flat and square a frame as possible;
- Take out the 4 pieces shown in the picture from the 8 profiles assembled earlier, connect them end to end, with the end faces facing outwards, and tighten the screws.

FRAME



FRAME ASSEMBLY

This design relies on blind joints to assemble the frame. We outlined the basics of blind joints on page 4.

More tips on how to assemble a frame are linked below.




WWW.FYSETC.COM






BUILD ON A FLAT SURFACE

- From the 8 aluminum profiles assembled earlier, take out the 4 pieces shown in the picture, connect them end to end;
- Repeat the previous work.

FRAME



WWW.FYSETC.COM




BUILD ON A FLAT SURFACE

- Take out the 4 aluminum profiles shown in the picture and insert them into the assembled profile base from top to bottom;
- The notch of the bottom assembled profile faces upward, the arc surface of the four columns faces outward, and tighten the screws.

FRAME

WWW.FYSETC.COM




BUILD ON A FLAT SURFACE


- First install the M5 T-Nut on the 2020R profile;
- Take out the 4 aluminum profiles shown in the picture, place them on the base, and tighten the screws.

FRAME

B Extrusion



WWW.FYSETC.COM







BUILD ON A FLAT SURFACE

- Install the previously assembled frame on the upper part, seal the top, and tighten it with screws from the holes around it.

FRAME

WWW.FYSETC.COM



BUILD ON A FLAT SURFACE




- Install the printing platform support profile at the bottom, 2040 on both sides and 4040 in the middle. Pay attention to the gap in the profile.

FRAME

WWW.FYSETC.COM


BUILD ON A FLAT SURFACE

- First put the M5 T-Nut into the profile;
- Use M5x8 screws and angle brackets to fix on both sides (2040 on both sides and 4040 in the middle, pay attention to the gap in the profile).



Z-axis belt idler assembly

WWW.FYSETC.COM




ASSEMBLY

- Take out the machined parts of the belt tensioner and assemble as shown above. Quantity: left x2, right x2.

Z-axis belt idler assembly




WWW.FYSETC.COM



ASSEMBLY

- Place the belt tensioner on the profile base, flush with the profile top surface, and pay attention to distinguish between left and right.
- Assemble as shown in the diagram, quantity: left x2, right x2, the diagonal parts are the same, pay attention to the idling direction.





Z-Motor assembly



First remove the two screws on the motor tailstock

WWW.FYSETC.COM

Right




ASSEMBLY

- Take out the Z-axis motor and the corresponding machined parts, pay attention to distinguish the left and right, and assemble them according to the diagram.. Quantity: left x2, right x2.





Z-Motor assembly

WWW.FYSETC.COM

Left



First remove the two screws on the motor tailstock





ASSEMBLY

- Take out the Z-axis motor and the corresponding machined parts, pay attention to distinguish the left and right, and assemble them according to the diagram. Quantity: left x2, right x2.

Z-Motor assembly

WWW.FYSETC.COM








ASSEMBLY

- Place the Z-axis motor assembly on top of the profile frame, flush with the upper surface of the profile, pay attention to distinguish between left and right, and assemble as shown above.
- Assemble as shown in the figure. Quantity: left x2, right x2, diagonally the same. Pay attention to the idling direction. The motor and the idler wheel must be consistent.



ASSEMBLY

- Install the motor wires according to the arrows in the figure.
- Place the motor wires in the slot and cover them with aluminum profile slot seals.



Z-axis Rail installation


WWW.FYSETC.COM



ASSEMBLY

- Install the Z-axis guide rail on the column, flush with the bottom surface of the profile, and be careful not to let the guide rail slider fall off, Note that the guide rail and the motor are on the same side;
- Use M3x12 screws on the top of the guide rail to fix the printed part to prevent the slider from falling off.



Z-axis Guide rail connector installation



M3x6 BHCS

WWW.FYSETC.COM


GE5C



M3x8 SHCS



ASSEMBLY

- First install the GE5C fisheye bearing in the connector slot and tighten the screws;
- Install the connector on the Z-axis guide rail slider and tighten the screws.




OVERVIEW



WWW.VORONDESIGN.COM



B-Drive Components



WWW.FYSETC.COM



ASSEMBLY

- Prepare the materials as shown in the figure;
- Use screws to assemble them;
- Finally, use M3x40 screws to fix the motor (If the screw is longer, add an M3 washer) ;
- Pay attention to the direction of the motor wiring port.


CHECK YOUR WORK

- Compare your assembled part to the graphic shown here;
- Pay attention to the pulley orientation and alignment with the bearing stack ups.



UPSIDE DOWN ASSEMBLY

- For ease of assembly we recommend to assemble the A and B drives upside down;

A-Drive Components



WWW.FYSETC.COM



ASSEMBLY

- Prepare the materials as shown in the figure;
- Use screws to assemble them;
- Finally, use M3x40 screws to fix the motor (If the screw is longer, add an M3 washer) ;
- Pay attention to the direction of the motor wiring port.

CHECK YOUR WORK




- Compare your assembled part to the graphic shown here;
- Pay attention to the pulley orientation and alignment with the bearing stack ups.

UPSIDE DOWN ASSEMBLY

- For ease of assembly we recommend to assemble the A and B drives upside down;

XY-Joint Right

WWW.FYSETC.COM





ASSEMBLY

- Prepare the materials as shown in the figure;
- Use screws to assemble them;
- Be careful not to tighten all the screws.

XY-Joint Left


WWW.FYSETC.COM



ASSEMBLY

- Prepare the materials as shown in the figure;
- Use screws to assemble them;
- Be careful not to tighten all the screws.

A Idler





ASSEMBLY

- Prepare the materials as shown in the figure;
- Use screws to assemble them;
- Be careful not to tighten all the screws.


B Idler

WWW.FYSETC.COM







Gantry Components





ASSEMBLY

- Prepare the materials as shown in the figure;
- Locking screw.

WWW.FYSETC.COM






ASSEMBLY

- Install 2 Pcs linear guide rails MGN9H (length 760mm) on the bottom of the profile;
- Use M3x8 FHCS for fixing, locking screw.


Gantry Components

WWW.FYSETC.COM




ASSEMBLY

- First, solder the connecting wire at one end of the light strip (refer to the wiring diagram for wiring);
- Insert the light strip into the profile and stick it in the center;
- Install 1 Pcs linear guide MGN12H (length 765mm) on the side of the profile, Use M3x8 FHCS for fixing;
- Install the left/right XY joints on both sides of the profile and tighten the screws (make sure the light bar is on the bottom);



ASSEMBLY

- Install the gantry X-axis assembly on the frame;
- Use M3x8 FHCS at both ends to fix the slider;





ASSEMBLY


- Install the belt as shown;

Gantry Components


WWW.FYSETC.COM




M3x6 BHCS



M3x8 FHCS



M2x10 FHCS




M3x8 FHCS

M2x10 FHCS

XY Micro Switch

ASSEMBLY

- After the belt is put on, use Cartographer CNC toolhead to fix it, and use M3x6 BHCS to tighten the belt;
- Use M3x8 FHCS to fix the IDM ScannerCNC metal parts on the guide rail slide;
- Use M2x10 FHCS to fix 1 Pcs of micro switches on the printed part and 1 Pcs on the metal part;
- Install the micro switch print on the IDM ScannerCNC metal part and fix it with M3x8 FHCS;






ASSEMBLY

- Place the assembled gantry components into the frame;


Gantry Components

WWW.FYSETC.COM




ASSEMBLY

- Pass the belt through the reduction motor and idler pulley as shown, and then fix it to the gantry assembly;



ASSEMBLY

- Use M5x22 FHCS screws to pass through: $\Phi 5 \times \Phi 10 \times H10\text{mm}$, and tighten with CNC Washer at intervals;
- Repeat the previous operation to fix the gantry;





ASSEMBLY

- Install AB motor cooling fan;
- Tear off the sticker on the back of the heat sink and stick it on the tailstock of the motor;

DECK PANEL

WWW.FYSETC.COM




ASSEMBLY

- Place the acrylic sheet on the bottom of the frame;
- Use M3x6 BHCS to fix the acrylic sheet to the profile frame;

HEATED BED

WWW.FYSETC.COM



Isolation column

Rectangular spring



M3 T-Nut

ASSEMBLY

- Place an M3 ball nut in the profile groove;
- Put the spring through the black nylon isolation column and place it in the acrylic plate groove;
- The hole of the ball nut should be consistent with the hole of the profile;

HEATED BED

WWW.FYSETC.COM




ASSEMBLY

- Glue the silicone heating pad to the back of the hot bed in the center;
- Glue the insulation cotton to the silicone heating pad;
- Use the cylindrical head hexagon socket M3x8 screw to connect the hot bed ground wire;


HEATED BED

WWW.FYSETC.COM




ASSEMBLY

- Place the 4 hotbeds on the springs;
- Use the M3x30 SHCS screws to tighten, and screw them to the bottom;
- Stick the 4 magnetic tiles of the hotbed to the aluminum plate and scrape them flat without bubbles;




HEATED BED


WWW.FYSETC.COM









ASSEMBLY

- Pass all the wires of the hot bed through this hole;
- And mark the power cord and thermistor wire of the hot bed with sticky notes according to the diagram for later wiring;











Printout needs
updating



M3 Threaded Insert

ASSEMBLY

- Use a soldering iron to heat-weld the printed parts:


※Printout needs updating

(Chain_Anchor_3_Hole_V2_Trident-G) .

https://github.com/FYSETC/Venture_XL/tree/main/STLs





STEALTHBURNER

WWW.FYSETC.COM







STEALTHBURNER

WWW.FYSETC.COM



ASSEMBLY

- Assemble according to the diagram;
- The blade in step ③ needs to be pressed in. The blade must be sharp and pay attention to safety.;
- Complete the assembly together with the reference wiring diagram;




ASSEMBLY

- Assemble according to the diagram;
- Complete the assembly together with the reference wiring diagram;




STEALTHBURNER

WWW.FYSETC.COM







ASSEMBLY

- Assemble according to the diagram;
- Step ④: The CAB expansion board needs to be installed behind the 5015 Fan;
- Step ⑤: The CAN expansion board needs to be connected to the CAN board pins;
- Complete the assembly together with the reference wiring diagram;





ASSEMBLY

- The CAN board line is inserted from the drag chain;
- Use M3x8 BHCS screws to fix one end of the drag chain to the extruder head and the other end to the profile;
- The back of the XY drag chain is fixed with a drag chain buckle;



ASSEMBLY

- Assemble according to the diagram;
- The light bar cable is connected to port ①, See page 33;
- Port ② faces the drag chain and uses the power cable to connect to the CAN board;




M3 T-Nut

M3x8 SHCS



ASSEMBLY

- First, pass the AB motor wires and CAN board connection wires through the drag chain;
- Fix the drag chain with the drag chain fixings and tighten the screws;



Caster Installation

WWW.FYSETC.COM





ASSEMBLY

- Turn the machine over and install the caster fixing plate first;
- Then install the casters and tighten the screws;
- Install 4 casters in sequence;



HEATED BED - Connection line

WWW.FYSETC.COM



ASSEMBLY

- Connect the four neutral wires from the bed heaters (the wires with the ferrule on the end) and insert into the screw terminal bus bar along with the Blue neutral wire that will go to the electronics enclosure;
- And use screws to fix the wiring terminal to the profile;
- The hotbed power wire and motor wire pass through the hole in the red frame;
- The gray display cable passes through the green frame;
- Complete the assembly together with the reference wiring diagram;




M3 T-Nut

M3x8 SHCS



ASSEMBLY

- The gray cable of the display screen is fixed along the profile;
- The screws are tightened;

LCD





WWW.FYSETC.COM



ASSEMBLY

- The display has been assembled, and the back cover needs to be removed first;
- Insert one end of the gray cable into the red area on the drawing;
- Tighten the screws and install it on the profile, centering it;








ASSEMBLY

- Tear off the protective paper on both sides of the acrylic board;

Electric Box

WWW.FYSETC.COM





ASSEMBLY

- Assemble according to the diagram;
- Install the handle and lock inside the electrical box;

Electric Box

WWW.FYSETC.COM





ASSEMBLY

- First, screw the electric box to the side of the profile;
- Pass the display screen, motor, heat bed, and CAN board wires through the window and connect them to the main board.
- Refer to the wiring diagram for the installation position;

Electric Box

WWW.FYSETC.COM




ASSEMBLY

- First remove the fan and its bracket;
- Pass the display screen, motor, heat bed, and CAN board wires plug into the motherboard;
- Refer to the wiring diagram for the installation position;



Wiring Diagram

WWW.FYSETC.COM




Material Rack

WWW.FYSETC.COM



ASSEMBLY

- Assemble according to the diagram;
- The bracket is placed in the middle of the profile;




ASSEMBLY


- Initial installation of equipment completed;
- After checking the circuit, you can try to power on the machine;

NEXT STEPS


WWW.FYSETC.COM




Acrylic plate fixing_1_x8




Acrylic plate fixing_2_x10




Acrylic plate fixing_3_x16




Door Block + Camera
Bracket_up_x1




Feed port_x4




Door Block_down_x1




Door corner stopper_x8



Door handle_x2




Door handle corner
plug_x2




Profile End Cap_x4

ASSEMBLY


- After the equipment is turned on and running, print the graphic file, black PETG, filling 30%;



Acrylic plate fixing_1_x8




Acrylic plate fixing_2_x10




Acrylic plate fixing_3_x16


ASSEMBLY

- Use a soldering iron to heat-weld the printed parts;






6x3mm Neodimium
Magnet




ASSEMBLY

- Press the magnet into the print as shown;




ASSEMBLY

- Open the camera box and take out the camera;
- Remove the bracket behind the camera from the middle connection;
- Install the camera body to the bracket and tighten it with screws;



Sealing


WWW.FYSETC.COM





ASSEMBLY

- Assemble according to the diagram;
- Install the acrylic board bracket and pay attention to the installation position;

Side Panel



WWW.FYSETC.COM




ASSEMBLY

- Take out the profile shown in the figure;
- Insert the acrylic sheet into both sides of the profile as shown in the picture;
- Mount the acrylic sheet to the frame;

Side Panel


WWW.FYSETC.COM





ASSEMBLY

- Assemble according to the diagram;
- Tighten the screws to fix the acrylic plate to the bracket;

Back Panel




WWW.FYSETC.COM




ASSEMBLY

- Take out the profile shown in the figure;
- Insert the acrylic sheet into both sides of the profile as shown in the picture;
- Mount the acrylic sheet to the frame;



ASSEMBLY


- Assemble according to the diagram;
- Tighten the screws to fix the acrylic plate to the bracket;





ASSEMBLY

- First loosen the screws of the electric box and remove the electric box;

Side Panel




WWW.FYSETC.COM



ASSEMBLY


- Take out the profile shown in the figure;
- Insert the acrylic sheet into both sides of the profile as shown in the picture;
- Mount the acrylic sheet to the frame;




ASSEMBLY

- Assemble according to the diagram;
- Install the acrylic board bracket and pay attention to the installation position;

Side Panel




WWW.FYSETC.COM





ASSEMBLY

- Install the electrical box back onto the frame;

Top Panel



WWW.FYSETC.COM






ASSEMBLY

- Take out the profile shown in the figure;
- Insert the acrylic sheet into both sides of the profile as shown in the picture;
- Mount the acrylic sheet to the frame;

Top Panel

WWW.FYSETC.COM




ASSEMBLY

- Take out the accessories package and there are 2 Pcs 24V LED light strips;
- The light strips need to be connected in series
- The installation position is not fixed and can be installed at will. The picture provides 2 installation positions;
- Wiring location, refer to the wiring diagram;



Top Panel

WWW.FYSETC.COM



ASSEMBLY

- Assemble according to the diagram;
- Tighten the screws to fix the acrylic plate to the bracket;




ASSEMBLY

- Assemble according to the diagram, Covering Wires;
- Tighten it with screws;



Door

WWW.FYSETC.COM




Door

WWW.FYSETC.COM




M3x5 BHCS





ASSEMBLY

- Insert "Door corner stopper" into the profile groove;
- Assemble according to the diagram;
- Tighten it with screws;



Door

WWW.FYSETC.COM





ASSEMBLY

- Insert the acrylic sheet into both sides of the profile as shown in the picture, close the end cover;
- Tighten it with screws;

Door

WWW.FYSETC.COM





ASSEMBLY

- Take the hinges out of the accessories bag;
- Install the hinge and tighten it with the hexagonal nut;
- Repeat the previous operation to assemble the remaining door;

Door

WWW.FYSETC.COM





ASSEMBLY

- Installing the door on the profile frame;
- Tighten it with screws;

Feed Port

WWW.FYSETC.COM





ASSEMBLY

- Assemble according to the diagram;
- Tighten it with screws;

Decorate

WWW.FYSETC.COM



Profile End Cap_x4

ASSEMBLY

- Press the profile end cap into the top of the frame and press it in;

NEXT STEPS

WWW.FYSETC.COM

ASSEMBLY COMPLETED! ... NEXT STEP: SETUP & CALIBRATION

This manual is designed to be a reference manual for the build process of a Venture_XL printer. Additional details about the build and background on advanced topics can be found on our documentation page linked below.


The software setup and other initial setup steps with your new printer can also be found on our documentation page. We recommend starting [here](#).

GitHub

https://github.com/FYSETC/Venture_XL

HOW TO GET HELP

If you need assistance with your build, we're here to help. Head on over to our Discord group and post your questions. This is our primary medium to help VORON Users and we have a great community that can help you out if you get stuck. Alternatively, you can use our subreddit.



<https://discord.gg/khdETAcYW2>

REPORTING ISSUES

Should you find an issue in this document or have a suggestion for an improvement please consider opening an issue on GitHub (https://github.com/FYSETC/Venture_XL).

When raising an issue please include the relevant page numbers and a short description; annotated screenshots are also very welcome.

We periodically update the manual based on the feedback we get.

WWW.FYSETC.COM

Enjoy your printer.

