



Installation Guide — Adhesive

WHAT YOU'LL NEED

- Masking tape or painter's tape
- Rubbing alcohol + clean cloth
- Level (or measuring tape)
- Hair dryer (cold weather only)

▲ TEMPERATURE CHECK

Install only when the surface is **10°C (50°F) or warmer**. In cold weather, warm the surface with a hair dryer. Avoid heat guns — they can damage both the surface and the numbers.

1 Clean the surface

Wipe the mounting area with a 50/50 mix of rubbing alcohol and water. Let it dry completely. A clean, dry surface is essential — oil, dust, or moisture will weaken the bond.

2 Plan your layout

Using masking tape, position each number or letter where you want it. Use a level to confirm they're straight or measure from the nearest horizontal edge with a tape measure. Mark each position lightly with tape or pencil before removing.

NOTE — ROUNDED CHARACTER ALIGNMENT

Fonts are purposely designed to look good to the eye when installed together, no matter what shape they are. Please use this guide when planning your number layout for a beautiful professional looking installation!



3 Press and hold

Peel off the adhesive backing. Press each character firmly in place and hold for **30 seconds**. Apply about **15 lbs of pressure** — to calibrate, press your thumb on a bathroom scale until it reads 15 lbs.

4 Allow to cure

The adhesive bonds quickly but reaches **full strength after 24–72 hours**. Avoid pulling on the characters or exposing them to heavy rain during this window.

ROUGH OR TEXTURED SURFACES — ALTERNATE METHOD

Use outdoor-rated silicone instead of the adhesive backing. Apply silicone to the back of the number, leaving space for a dab of hot glue and press into position.