



## Installation Guide – Stand-offs

### WHAT YOU'LL NEED

- Power drill
- Small brush or vacuum
- Included: templates, bolts, spacers
- 1/4" (6.35mm) drill bit\*
- Outdoor-rated silicone sealant

\* Use a masonry bit for stucco, brick, or concrete.

### HOW THE HARDWARE WORKS

Each bolt has two ends that do different jobs:

INTO BACK OF  
NUMBER / LETTER



INTO MOUNTING  
SURFACE

### 1 Tape the templates and plan your layout

Tape the included character templates to your mounting surface. Check that they are level and spaced evenly to your liking.

#### NOTE – ROUNDED CHARACTER ALIGNMENT

Fonts are purposely designed to look good to the eye when installed together, no matter what shape they are. Please use this guide when planning your number layout for a beautiful professional looking installation!



### 2 Drill the holes

Using a **1/4" (6.35mm) drill bit**, drill through the marked holes in the templates. Remove the templates and clean out each hole with a small brush or vacuum. Drill to approximately the depth of the pin end of the bolt.

### 3 Assemble each character

Slide the spacer(s) onto the bolt. Thread the **fine-threaded end** into the back of the number or letter – hold the bolt straight, apply gentle pressure, and turn clockwise. It will screw in.

#### ⚠ DO NOT OVERTIGHTEN

Hand-tight only. Overtightening will cause the material to delaminate and void your warranty.

### 4 Test fit (dry run – no silicone yet)

Push each assembled character into its holes and check that everything lines up and spacing looks right. This is your chance to adjust. Remove the characters once you're satisfied.

### 5 Final installation

Apply a small amount of outdoor-rated silicone **into each hole** and **onto each pin**. Push the characters into place and hold briefly. The silicone seals out moisture and locks the installation. Keep dry for **24 hours to cure**.