

---

Format           CALL POKER(vdp-number,numeric-variable[,...])

                  CALL POKER(numeric-variable,number[,...])

### Description

The POKER command writes to vdp register a byte value. Only registers 0 to 63 are valid. The byte value ranges 0 to 255. The number of Registers were increased to 63 VDP Registers for use with F18 register set.

### Programs

This sets TEXT mode.	>100 CALL POKER(7,244,1,240)
This is a delay loop.	>110 FOR L=1 TO 500 :: NEXT L
This sets MULTI COLOR mode	>120 CALL POKER(1,232)
This is a delay loop.	>130 FOR L=1 TO 500 :: NEXT L
This sets BIT MAP mode.	>140 CALL POKER(0,2,1,2)
This is a delay loop.	>150 FOR L=1 TO 500 :: NEXT L
This sets NORMAL XB mode.	>160 CALL POKER(0,0)
This resets memory.	>170 CALL NEW