

Introducing the Rubix iO Modules - Nube iO's highly adaptable, cost-effective physical Input/Output solution. These compact modules offer extensive modular monitoring and control capabilities for building management systems (BMS).

Easily integrated with the Rubix Compute through direct plug-in or RS485 wiring, the Rubix iO Modules serve as both building management systems (BMS) components and standalone HVAC application controllers. Utilising Modbus for configuration and monitoring, they enable affordable, distributed control and centralised supervision of various system types.

As a pure Modbus device, the Rubix iO Modules are compatible with a wide range of systems beyond the Nube iO platform. For enhanced flexibility, an optional LoRa® wireless version allows for long-range, object interference-resistant communication with the iO Modules.

When utilising LoRa® wireless technology, the RS485 port functions as a Modbus pass-through, enabling wireless communication with any wired (RS485) Modbus device. Experience seamless connectivity and versatile control with the Rubix iO Modules.



Technical Data

General	
Dimensions	112mm x 65mm x 56mm or 4.41in x 2.56in x 2.20in
Operating Temperature	0°C to 65°C ABS Plastic, DIN Rail Mount, IP20 Rated
Enclosure	0°C to 65°C ABS Plastic, DIN Rail Mount, IP20 Rated
Power	
Power Supply	24VDC ±10%
Consumption	Base: 1.2W (50mA at 24 VDC), Max: 36W (1500mA at 24 VDC)

Recommended Transformer Size	1A / 25VA (Transformer should be sized based on Base Current plus the power requirements of all connected output devices)		
Physical Ports			
RS485	1x RS485 Modbus RTU ports. 3 Wire. Speed: 9.6K, 19.2k, 38.4K bit/s Data Bits: 8 bits Parity: None		
Wireless Communications			
LoRa®	Supported Frequencies: AU915, US915, AS232, EU863 Spreading Factor: 7 Bandwidth: 250 kHz		
Low Level iO	IO-11	IO-16	Description
Universal Inputs (UI)	6	8	Configurable as Digital, 0-10VDC, or 10k Thermistor.
Digital Outputs (DO)	2	0	0V[OFF], 12VDC[ON] (200mA).
Universal Outputs (DO)	5	8	0-10VDC, or Digital - 0V[OFF] - 12VDC[ON] (200mA).

Configuration

DIP Switch Settings																																																							
Left Bank (SW2) - DIP 1-7	Modbus Address set as binary + 1. <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>Address</th> <th>1</th> <th>2</th> <th>3</th> <th>4</th> <th>5</th> <th>6</th> <th>7</th> <th>8</th> </tr> </thead> <tbody> <tr> <td>0000</td> <td>0000</td> <td>0000</td> <td>0000</td> <td>0000</td> <td>0001</td> <td>0001</td> <td>0001</td> <td>0001</td> </tr> <tr> <td>00</td> <td>01</td> <td>10</td> <td>11</td> <td>00</td> <td>01</td> <td>10</td> <td>11</td> <td></td> </tr> <tr> <th>Switches 1,2,3,4,5,6</th> <th>9</th> <th>10</th> <th>11</th> <th>12</th> <th>13</th> <th>14</th> <th>15</th> <th>16</th> </tr> <tr> <td>0010</td> <td>0010</td> <td>0010</td> <td>0010</td> <td>0011</td> <td>0011</td> <td>0011</td> <td>0011</td> <td>0011</td> </tr> <tr> <td>00</td> <td>01</td> <td>10</td> <td>11</td> <td>00</td> <td>01</td> <td>10</td> <td>11</td> <td></td> </tr> </tbody> </table>	Address	1	2	3	4	5	6	7	8	0000	0000	0000	0000	0000	0001	0001	0001	0001	00	01	10	11	00	01	10	11		Switches 1,2,3,4,5,6	9	10	11	12	13	14	15	16	0010	0010	0010	0010	0011	0011	0011	0011	0011	00	01	10	11	00	01	10	11	
	Address	1	2	3	4	5	6	7	8																																														
0000	0000	0000	0000	0000	0001	0001	0001	0001																																															
00	01	10	11	00	01	10	11																																																
Switches 1,2,3,4,5,6	9	10	11	12	13	14	15	16																																															
0010	0010	0010	0010	0011	0011	0011	0011	0011																																															
00	01	10	11	00	01	10	11																																																
Left Bank (SW2) - DIP 8	Must be set to 1 for normal operation. No other functionality.																																																						
Right Bank (SW1) - DIP 1-2 Operation Mode	<table border="1" style="margin-left: 20px;"> <thead> <tr> <th>Mode</th> <th>RS485 (Wired)</th> <th>LoRa® Wireless</th> <th>RS485 to LoRa® Passthrough *</th> <th>IO Reset **</th> </tr> </thead> <tbody> <tr> <td>Switch 1,2</td> <td>00</td> <td>10</td> <td>01</td> <td>11</td> </tr> </tbody> </table> <p>* Use this setting when connecting to 3rd party Modbus Devices. ** Set DIP switches, and power cycle, then set back to operation mode setting.</p>	Mode	RS485 (Wired)	LoRa® Wireless	RS485 to LoRa® Passthrough *	IO Reset **	Switch 1,2	00	10	01	11																																												
Mode	RS485 (Wired)	LoRa® Wireless	RS485 to LoRa® Passthrough *	IO Reset **																																																			
Switch 1,2	00	10	01	11																																																			

Right Bank (SW1) - DIP 3-5	Baud Rate	38400	9600	19200
	Switch 3,4,5	000	100	010
Right Bank (SW1) - DIP 6-7	Parity	None	Even	Odd
	Switch 6,7	00	10	01
Right Bank (SW1) - DIP 8	Must be set to 1 for normal operation. No other functionality.			

About Nube iO

Nube iO stands at the forefront of building technology, providing innovative software and hardware solutions. We're dedicated to enhancing building operations, sustainability and compliance by providing secure connectivity, seamless system operability, and delivering all-encompassing monitoring, analysis, and control. Our team leads innovation in the building industry.

We tackle the integration of diverse systems and modernise legacy technologies to streamline operations and improve functionality. Our innovative approach ensures seamless connectivity across devices and protocols, making Nube iO a go-to for end-to-end building automation, sustainability and asset management solutions.

To learn more about our products and solutions, visit: nube-io.com

Document Code	RIO2408
Person Responsible	CBO
Date Last Updated	26/2/24
Status	Release V1.0
Location	Products