


Taranis X9D 6-Positions Encoder Step-by-Step Manual

Firmware Support: Above V1.2.0


Download newest firmware on: <http://www.frsky-rc.com/download/>

Hardware Support: Taranis X9D- all versions

Step 1: 6-Positions Encoder and X9D inner wires Definition




Step 2: Pull out the marked Cap and unscrew the Nut, and Open Taranis X9D radio case



Step 3: Cut the original three wires, and soldering wires in corresponding [Pins Definition](#) (In Step 1 pictures)

Step 4: Mounting the 6-positions encoder



Step 5: Close radio case